



DIY

User Manual

Model Code: 3033

THANK YOU FOR YOUR ORDER

Contents

- 1 Front Cover
 - _
- 2 Safety
 - Instructions
 - _
- 2 Warnings
 - -
- 3 Operating
 - Instructions
 - -
- 4 Back Cover

End



48 Inch Farm Jack

OYPL3

Model Code: 3033

Oypla.com LLP / www.oypla.com

Contents

Front Cover

Instructions

Warnings

Operating

Instructions

Back Cover

End

Safety

1

2

2

3

4

Safety Instructions

Notice: Ensure you read and fully understand instructions before use

While every attempt is made to ensure the highest degree of protection in all equipment, we cannot guarantee freedom from injury. The user assumes all risk of injury due to use. All merchandise is sold on this condition, which no representative of the company can waive or change.

- Never carry out alterations or modifications to this product.
- This product is not a toy, and is only to be used for its designated purpose.
- Only use this product on stable, level and dry ground.
- Ensure that the load is stabilised so that it will not shift when it is being lifted or lowered.
- This product is not intended for use by persons (including children) with reduced physical, sensory and mental capacities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning the use of the product by persons responsible for their safety.
- If the product is damaged or defective, please contact cservice@oypla.com

- Ensure the jack won't slip once the load has been applied.
- Do not work underneath a vehicle once raised unless you have additional supporting stands.
- Do not push the load off the jack lower it carefully.
- Do not use handle extensions.
- Do not carry the jack by its handle.
- Leaving the product outside exposed to weather, especially direct sun, rain and salt air, will speed the weathering process. This can be slowed by removing the product from these conditions, or covering it with a suitable cover.
- Clean only using a damp cloth. Do not use strong industrial cleaning substances or abrasive materials, as these may damage the product.

Warnings

⚠ Do not overload the product. The maximum weight it can accommodate is 3000kg.

A Ensure the instructions in this booklet are followed closely, to avoid potential injury and/or product failure.

Contents

Front Cover

Instructions

Warnings

Operating

Instructions

Back Cover

End

Safety

1

2

2

3

4

Operating Instructions

Please refer to the information below for instructions on how to operate your product.

TO RAISE A LOAD

- 1. Following all safety precautions, place the foot of the jack beneath the load. Lift the reversing latch (17) to its UP position and ensure it is locked in place; with the indentation on the latch firmly engaged in the notch on the reversing switch (18) refer to Fig. 1.
- 2. Jack up the nose until it comes into contact with the load at the desired point of lift. Pause at this stage and check to ensure there are no obstacles preventing a clean lift.
- 3. Pull down firmly and evenly on the handle and observe the load rising. As the handle is pulled down, you will hear the climbing pin (13) click into place as it locates a hole in the steel bar (3). At this point, relax the handle allowing the pin to take the load.
- 4. Raise the handle to the top of its stroke and repeat step 3 until your desired height is reached.

TO LOWER A LOAD

IMPORTANT: The jack must be loaded with a minimum of 50KG (110LBS) to lower step by step; otherwise, the lifting nose will drop.

- 1. Taking all necessary precautions, take the load with the jack (jack the load up slightly) and ensuring the handle is in the FULL UPRIGHT position.
- 2. Trip the reversing latch (17) so that it is in the DOWN position; causing the indentation on the latch to become disengaged from the notch on the reversing switch refer to Fig. 2.
- 3. Keeping a firm grip on the handle, pull down firmly and evenly on the handle as you would for 'raising a load'.

TO RAISE A LOAD



TO LOWER A LOAD





Contents

1 Front Cover

-

SafetyInstructions

-

2 Warnings

-

3 Operating

Instructions

-

4 Back Cover

End

 ϵ



HAVE A QUESTION ABOUT YOUR PURCHASE?

Our dedicated customer services team are happy to help. Contact them via:

Telephone: 020 3600 22 55 Email: cservice@oypla.com Live Chat: WWW.OYPLA.COM

CONSIDER THE ENVIRONMENT!

In the United Kingdom, approximately 5 billion corrugated boxes are used per year, amounting to around 83 per person! By recycling the cardboard box in which this product was packed, you contribute to the preservation and sustainability of the environment.

If you see a recycling logo on the packaging of your product, such as the below examples, that piece of packaging is recyclable. If there is not a recycling logo, please check with your local authorities before recycling.









PLEASE RETAIN A COPY OF THESE INSTRUCTIONS FOR FUTURE CONSULTATION



AN OFFICIAL OYPLA BRANDED PRODUCT

Model Code: 3033

Oypla.com LLP / www.oypla.com

