



Wooden Chalkboard

Safety Instructions

Notice: Ensure you read and fully understand instructions before use

While every attempt is made to ensure the highest degree of protection in all equipment, we cannot guarantee freedom from injury. The user assumes all risk of injury due to use. All merchandise is sold on this condition, which no representative of the company can waive or change.

- Before using the chalkboard, make sure all fastenings are tightly in place and that everything is in order, and checked periodically.
- This product is not a toy, and is only to be used for its designated purpose.
- Leaving the chalkboard outside exposed to weather, especially direct sun, rain and salt air, will speed the weathering process. This can be slowed by removing the chalkboard from these conditions, or covering it with a suitable cover.
- Clean only with a damp cloth. Do not use strong industrial cleaning substances.
- Keep fingers, loose clothing, and hair away when folding the product. Pinch points can cause personal injury.
- Do not carry out alterations or modifications to this product
- If the product is damaged or has any defects, please contact cservice@oypla.com

HAVE A QUESTION ABOUT YOUR PURCHASE?

OUR DEDICATED CUSTOMER SERVICES TEAM ARE HAPPY TO HELP
CONTACT THEM VIA:

TELEPHONE: 020 3600 2255

EMAIL: cservice@oypla.com

LIVE CHAT: www.oypla.com

PLEASE RETAIN A COPY OF THESE INSTRUCTIONS FOR FUTURE CONSULTATION

OYPLA.COM

An Official OYPLA Branded Product

Imported by Oypla.com LLP, Uxbridge, UB8 2FX

USER MANUAL Model No: 4050