

OYPLATM GARDEN



2x Artificial Pyramid Tree

Safety Instructions

Notice: Ensure you read and fully understand instructions before use

While every attempt is made to ensure the highest degree of protection in all equipment, we cannot guarantee freedom from injury. The user assumes all risk of injury due to use. All merchandise is sold on this condition, which no representative of the company can waive or change.

- Make sure all fastenings are tightly in place and that everything is in order before using the product. This should be checked periodically by an adult.
- Do not discard any of the packaging until you have checked that you have all of the parts and fittings required.
- Leaving the product outside exposed to weather, especially direct sun and rain, will speed the weathering process. This can be slowed by removing the product from these direct conditions.
- Keep product away from fire.
- Do not carry out alterations or modifications to this product.
- If the product is damaged or has any defects, please contact cservice@oypla.com

Assembly Instructions

Parts List:

If you are missing any of the below parts please contact cservice@oypla.com

Please be aware that you will be referring to this parts list throughout the assembly process.

Part	Qty
Artificial Pyramid Tree	2
Bracket	4
Small Screw	8
Large Screw	4
Rawl Plugs	4

1) Place the artificial tree in your desired position, and line two brackets up to the rear of the planter. Using a pencil or marking tool, lightly mark the hole positions on both the planter and the surface you wish to fasten the product to.

2) When all holes are marked, proceed to create pilot holes in both the planter and the surface you wish to attach the product to. It is important to **not** make the pilot holes wider than the screws in the planter, and **not** wider than the rawl plugs for the surface you are attaching the product to. A 5mm drill bit for creating pilot holes in the floor surface is recommended IF the surface is concrete, and/or requires rawl plugs. If it is wood, the rawl plugs are not necessary and the screws can be inserted without plugs.

3) When all pilot holes are created, proceed to insert the small screws into the planter, and the large screws into the attaching surface. Use a rawl plug to ensure the attaching surface does not suffer damage from inserting screws (if required – see step 2). The artificial plant should now be attached to the surface when all plugs/screws are inserted.

HAVE A QUESTION ABOUT YOUR PURCHASE?

OUR DEDICATED CUSTOMER SERVICES TEAM ARE HAPPY TO HELP
CONTACT THEM VIA:

TELEPHONE: 020 3600 2255

EMAIL: cservice@oypla.com

LIVE CHAT: www.oypla.com

PLEASE RETAIN A COPY OF THESE INSTRUCTIONS FOR FUTURE CONSULTATION

OYPLA.COM

An Official OYPLA Branded Product

Imported by Oypla.com LLP, Uxbridge, UB8 2FX

USER MANUAL Model No: 4539