

# DIY

User Manual

Model Code: 3071

THANK YOU FOR YOUR ORDER

## Contents

- 1 Front Cover  
-
- 2 Safety  
Instructions  
-
- 2 Warning  
Instructions  
-
- 3 Assembly  
Instructions  
-
- 6 Back Cover

End



## Trailer Dolly

## Contents

1	Front Cover
-	-
2	Safety Instructions
-	-
2	Warning Instructions
-	-
3	Assembly Instructions
-	-
6	Back Cover
	End

# Safety Instructions

## Notice: Ensure you read and fully understand instructions before use

While every attempt is made to ensure the highest degree of protection in all equipment, we cannot guarantee freedom from injury. The user assumes all risk of injury due to use. All merchandise is sold on this condition, which no representative of the company can waive or change.

- This product is not a toy, and is only to be used for its designated purpose.
- This product is intended for outdoor use only.
- Do not carry out alterations or modifications to this product.
- Clean only with a damp cloth. Do not use strong industrial cleaning substances.
- Leaving the product outside exposed to weather, especially direct sun, rain and salt air, will speed the weathering process. This can be slowed by removing the product from these conditions, or covering it with a suitable cover.
- Before using the product, make sure all the fastenings are tightly in place and that everything is in order, and checked periodically by an adult.
- Always make sure the trailer is blocked properly before moving the dolly into place.
- The maximum weight capacity is 275kg for the trailer dolly alone and does not include the load supported by the trailer wheel.
- Always keep arms, feet and legs etc. away from the trailer tongue while hitching, unhitching or moving the trailer. Keep children and bystanders at a safe distance.
- Take precautions to prevent uncontrolled movement of the trailer once it is connected to the dolly. The slope of a road can be difficult to judge and may result in an out of control trailer.
- If the product is damaged or has any defects, please contact [cservice@oypla.com](mailto:cservice@oypla.com).

## Warnings

⚠ This products maximum weight is 275kg. Do not exceed this as this may lead to personal injury and/or product failure.






## Contents

1	Front Cover
-	
2	Safety Instructions
-	
2	Warning Instructions
-	
3	Assembly Instructions
-	
6	Back Cover
	End

# Assembly Instructions

## Parts List:







- If you are missing any of the below parts, please contact [cservice@oypla.com](mailto:cservice@oypla.com)
- Please be aware that you will be referring to this parts list throughout the assembly process.

PART	QTY	PART NUMBER
	<b>1</b>	<b>1</b>
	<b>1</b>	<b>2</b>
	<b>1</b>	<b>3</b>
	<b>1</b>	<b>4</b>
	<b>1</b>	<b>5</b>

## Contents

1	Front Cover
-	-
2	Safety Instructions
-	-
2	Warning Instructions
-	-
3	Assembly Instructions
-	-
6	Back Cover

End

	<b>Tow Bar</b>	<b>1</b>	<b>6</b>
	<b>Wheels</b>	<b>2</b>	<b>7</b>
	<b>Large Nuts and Bolts</b>	<b>3</b>	<b>8</b>
	<b>Small Nuts and Bolts</b>	<b>4</b>	<b>9</b>
	<b>Medium Nut and Bolt</b>	<b>1</b>	<b>10</b>
	<b>Safety Pins</b>	<b>2</b>	<b>11</b>

## Contents

- 1 Front Cover
- 
- 2 Safety Instructions
- 
- 2 Warning Instructions
- 
- 3 Assembly Instructions
- 
- 6 Back Cover

End

1



Firstly, attach the middle support bar (3) to the bottom of the front axle (1) using 2 small nuts and bolts (9). Please see photo for guidance. Then, attach the front axle support (5), to the middle support bar using the 2 remaining small nuts and bolts. Secure tightly. Lastly, attach the other end of the front axle support to the middle section of the front axle using the 1 medium nut and bolt (10) provided. Secure tightly and move on to step 2.

2



For step 2, line up the handle bar (2) and the 2 pre-drilled holes at the end of the V Shaped Stand. Now line these up with the pre made holes left on the middle support bar (3) and secure in place using 2 of the large nuts and bolts (8). Now, use the last large nut and bolt and secure the other end of the V Shaped Stand to the handle bar. The extra hole is used when adjusting the length of the handle bar. Please see photo above for guidance.

3



For step 3, simply securely attach the tow bar (6) onto the top of the front axle (1). Please see photo for help and move onto part 4 on the next page.

Model Code: 3071

Oypla.com LLP / www.oypla.com



# Contents

- 1 Front Cover
- 
- 2 Safety Instructions
- 
- 2 Warning Instructions
- 
- 3 Assembly Instructions
- 
- 6 Back Cover

End

4



Finally, slide each wheel (7) onto the front axis and fasten them in place using the safety pins (11) through the pre made holes. Please see photo for reference.

## HAVE A QUESTION ABOUT YOUR PURCHASE?

Our dedicated customer services team are happy to help. Contact them via:

Telephone: 020 3600 22 55  
 Email: [cservice@oypla.com](mailto:cservice@oypla.com)  
 Live Chat: [WWW.OYPLA.COM](http://WWW.OYPLA.COM)

## CONSIDER THE ENVIRONMENT!

In the United Kingdom, approximately 5 billion corrugated boxes are used per year, amounting to around 83 per person! By recycling the cardboard box in which this product was packed, you contribute to the preservation and sustainability of the environment.

If you see a recycling logo on the packaging of your product, such as the below examples, that piece of packaging is recyclable. If there is not a recycling logo, please check with your local authorities before recycling.



PLEASE RETAIN A COPY OF THESE INSTRUCTIONS FOR FUTURE CONSULTATION

# OYPLA.COM

AN OFFICIAL OYPLA BRANDED PRODUCT