

Garment Clothes Rail

Safety Instructions

Notice: Ensure you read and fully understand instructions before use

While every attempt is made to ensure the highest degree of protection in all equipment, we cannot guarantee freedom from injury. The user assumes all risk of injury due to use. All merchandise is sold on this condition, which no representative of the company can waive or change.

- This product contains small parts that could be a choking hazard if swallowed. Keep these items away from children.
- Make sure all fastenings are tightly in place and that everything is in order before using the product. This should be checked periodically by an adult.
- This product is not a toy, and is only to be used for its designated purpose.
- Clean only with a damp cloth. Do not use strong industrial cleaning substances.
- Leaving the product outside exposed to weather, especially direct sun and rain, will speed the weathering process. This can be slowed by removing the product from these conditions.
- Children should not use this product at any time.
- Do not overload the product.
- Weight capacity 65KG.
- Assembly should be completed by a responsible adult.
- Never swing or hang on the garment rail.
- Only use this product on stable, level and dry ground.
- If any parts are missing or damaged, please contact cservice@oypla.com









Assembly Instructions

Parts List:


Please check you have all parts below before attempting to assemble this product.

If you are missing any of the below parts, please contact Oypla customer services:


cservice@oypla.com

A M6x30mm  2pcs	B M6x40mm  4pcs	E 2pcs 	H  1pcs
C  6pcs	D  6pcs	F 1pcs 	
		G 1pcs 	


1. Begin by taking parts E and Hx2pcs. Align part E and Hx2pcs up together making sure the screw holes align. Use screw Bx2, nuts Cx2 and nut cover Dx2 to secure the legs to the frame. DO NOT over tighten. Repeat this process once more.



2. Take part F and slide onto the two supporting legs you created in step one. Use screws Ax2pcs, nuts Cx2pcs and nut cover Dx2pcs to secure the bottom rail in place. Please see image above.



3. Now take the top rail G and gently slide onto parts E. Assistance is advised on this step to make sure everything is correctly aligned.



HAVE A QUESTION ABOUT YOUR PURCHASE?

OUR DEDICATED CUSTOMER SERVICES TEAM ARE HAPPY TO HELP
CONTACT THEM VIA:

TELEPHONE: 020 3600 2255

EMAIL: cservice@oypla.com

LIVE CHAT: www.oypla.com

PLEASE RETAIN A COPY OF THESE INSTRUCTIONS FOR FUTURE CONSULTATION

OYPLA.COM

An Official OYPLA Branded Product

Imported by Oypla.com LLP, Uxbridge, UB8 2FX

USER MANUAL Model No: 3137