



2kW Wall Mounted Patio Heater


Safety Instructions

Notice: Ensure you read and fully understand instructions before use

While every attempt is made to ensure the highest degree of protection in all equipment, we cannot guarantee freedom from injury. The user assumes all risk of injury due to use. All merchandise is sold on this condition, which no representative of the company can waive or change.

- Make sure all bolts are secured before using. The user takes all responsibility for the construction and placement of the product.
- Make sure the quartz tube heater is out of the reach of children to avoid potential hazards and injuries.
- Never leave the heater unattended.
- Once you are finished with the patio heater be sure to turn it off, leaving it on can be dangerous. Allow to cool before moving/storing.
- To protect against electrical shock, do not immerse cord, plug or any part of this appliance in water or any other liquid.
- Ensure the power supply to the socket into which the appliance is plugged, is in accordance with the rating label on the appliance and that the socket is earthed.
- Leaving the product outside exposed to weather, especially direct sun, rain and salt air, will speed the weathering process. This can be slowed by removing the product from these conditions, or covering it with a suitable cover.
- This product is not a toy, and is only to be used for its designated purpose.
- Do not carry out alterations or modifications to this product.
- This product is intended for outdoor use only.
- Clean only with a damp cloth. Do not use strong industrial cleaning substances. Never clean while hot or in use.
- If the product is damaged or has any defects, please contact cservice@oypla.com

Operating Instructions



1. The positions marked “1” are for fixing the heater to the bracket.
2. The positions marked “2” are for fixing the bracket to the wall.
3. At the desired height for the heater, firstly insert the rawl plugs at the shown distances in the diagram. Then screw the four M4x35 screws into the rawl plugs to secure the bracket to the wall. You can then attach the heater.
4. Turn the heater on by pulling on the cord found on the back of the heater enclosure. It has four heat settings; 0 (off), 1 (650W, low), 2 (1350W, medium) and 3 (2000W, high).

HAVE A QUESTION ABOUT YOUR PURCHASE?

OUR DEDICATED CUSTOMER SERVICES TEAM ARE HAPPY TO HELP
CONTACT THEM VIA:

TELEPHONE: 020 3600 2255

EMAIL: cservice@oypla.com

LIVE CHAT: www.oypla.com

PLEASE RETAIN A COPY OF THESE INSTRUCTIONS FOR FUTURE CONSULTATION



Environmental Protection

OYPLA.COM

An Official OYPLA Branded Product



Products bearing the symbol shown below means that used electrical and electronic equipment (WEEE) should not be mixed with general household waste. For proper treatment, recovery and recycling, please take this product(s) to designated collection points where it will be accepted free of charge. Disposing of this product correctly will help save valuable resources and prevent any potential negative effects on human health and the environment, which could otherwise arise from inappropriate waste handling. Please contact your local authority for further details of your nearest designated collection point. Penalties may be applicable for incorrect disposal of this waste, in accordance with your national legislation.



Imported by Oypla.com LLP, Uxbridge, UB8 2FX

USER MANUAL Model No: 3148