

Humane Animal Trap

Safety Instructions


Notice: Ensure you read and fully understand instructions before use

While every attempt is made to ensure the highest degree of protection in all equipment, we cannot guarantee freedom from injury. The user assumes all risk of injury due to use. All merchandise is sold on this condition, which no representative of the company can waive or change.


- This product is not a toy, and is only to be used for its designated purpose.
- Do not carry out alterations or modifications to this product.
- This product contains small parts that could be a choking hazard if swallowed. Keep these items away from children.
- Do not discard any of the packaging until you have checked that you have all the parts and fittings required.
- Make sure all fastenings are tightly in place and that everything is in order before using the product. This should be checked periodically by an adult.
- Never leave children unattended near this trap. Children should be supervised at all times when using the product.
- Do not attempt to handle any captured animals.
- Always wear heavy duty gloves when operating the trap.
- Clean only with a damp cloth. Do not use strong industrial cleaning substances.
- Leaving the product outside exposed to weather, especially direct sun and rain, will speed the weathering process. This can be slowed by removing the product from these conditions, or covering it with a suitable cover.
- If the product is damaged or has any defects, please contact cservice@oypla.com

Setting the Trap

1. Unfold the trap and ensure that the metal floor plate is flat. This plate will trigger the trap door.




2. Pull down the support arms and place under the bottom of the cage.




Support arm

3. Insert the lock wire through the designated holes and door rings to ensure the rear door doesn't open.




Lock wire

- Attach the trap hook to the floor plate and then to the U-bend spring clip on the door. Ensure the hook on the spring holds the door open in the cocked position.



- Once the trap is set correctly, the floor plate should raise about 5cm.



Releasing the Animal

- Lift the door up and insert a stick/tube through both sides of the trap keep the door open.
- Walk away from the trap and allow the animal to exit.

Animal	Suggested Bait
Rats, Weasels, Chipmunks and Flying Squirrels	cheese, peanuts, nuts, cereal, apples or seeds
Rabbits and Squirrels	fresh vegetables, cereals or nuts
Muskrats and Ferrets	fresh vegetables and apples
Skunks, Woodchucks and Opossums	fresh vegetables

HAVE A QUESTION ABOUT YOUR PURCHASE?

Our dedicated customer services team are happy to help. Contact them via:

Telephone: 020 3600 22 55
Email: cservice@oypla.com
Live Chat: WWW.OYPLA.COM

CONSIDER THE ENVIRONMENT!

In the United Kingdom, approximately 5 billion corrugated boxes are used per year amounting to around 83 per person! By recycling the cardboard box in which this product was packed, you contribute to the preservation and sustainability of the environment.

If you see a recycling logo on the packaging of your product, such as the below examples, that piece of packaging is recyclable. If there is not a recycling logo, please check with your local authorities before recycling.



PLEASE RETAIN A COPY OF THESE INSTRUCTIONS FOR FUTURE CONSULTATION

OYPLA.COM

AN OFFICIAL OYPLA BRANDED PRODUCT

Imported by Oypla.com LLP, Uxbridge, UB8 2FX

USER MANUAL Model No: 3323, 3782, 3783