

User Manual



Heat Lamp

USER MANUAL Model No: 3401, 3711, 3712

User Instructions


Notice: Ensure you read and fully understand instructions before use

While every attempt is made to ensure the highest degree of protection in all equipment, we cannot guarantee freedom from injury. The user assumes all risk of injury due to use. All merchandise is sold on this condition, which no representative of the company can waive or change.

- This product should only be connected to a 220-240V AC, 50Hz electrical outlet.
- This lamp is intended for bulbs with a maximum wattage of 250W.
- This product is intended for indoor use only.
- This product will become very hot while in use and remain hot for some time afterwards. DO NOT attempt to touch or hold the lamp when in use. Ensure the lamp is out of reach of children.
- Inspect the mains lead regularly. Never use the product if the mains lead or plug has been damaged in any way.
- DO NOT allow the mains lead to come into contact with the hot surface of the lamp.
- Ensure that the product is hung and mounted securely.
- This product is not a toy, and is only to be used for its designated purpose.
- The height of the lamp should be chosen according to each animal specifically, but the lamp should not touch the animal itself.
- The distance from the lamp to the floor should be no less than 50cm at any time.
- The lamp should always keep a distance of at least 60cm from any object while in use.
- Never use this product near any flammable or explosive materials.
- Never remove the wire cover/guard during heating.
- DO NOT discard of any packaging until you have checked that you have all of the parts and fittings required.
- If the product is damaged or has any defects, please contact cservice@oypla.com

Assembly Instructions

- Screw the bulb into the casing so that it is firmly secured. Make sure the bulb is not able to move and will not come loose during use of the lamp.
- Attach the bulb cover by inserting the tab into the mounting hole in the casing.
- Fold the cover back and secure in place with the remaining tab.



PLEASE RETAIN A COPY OF THESE INSTRUCTIONS FOR FUTURE CONSULTATION



OYPLA.COM



Environmental Protection

An Official OYPLA Branded Product

Products bearing the symbol shown below means that used electrical and electronic equipment (WEEE) should not be mixed with general household waste. For proper treatment, recovery and recycling, please take this product(s) to designated collection points where it will be accepted free of charge. Disposing of this product correctly will help save valuable resources and prevent any potential negative effects on human health and the environment, which could otherwise arise from inappropriate waste handling. Please contact your local authority for further details of your nearest designated collection point. Penalties may be applicable for incorrect disposal of this waste, in accordance with your national legislation.



Imported by Oypla.com LLP, Uxbridge, UB8 2FX

USER MANUAL Model No: 3401, 3711, 3712