

OYPOLEA™

LEISURE



QUANTITY AND ACCESSORIES MAY VARY

Heavy Duty Tripod

USER MANUAL Model No: 3496, 3458

Safety Instructions

Notice: Ensure you read and fully understand instructions before use

While every attempt is made to ensure the highest degree of protection in all equipment, we cannot guarantee freedom from injury. The user assumes all risk of injury due to use. All merchandise is sold on this condition, which no representative of the company can waive or change.

- This product is not a toy, and is only to be used for its designated purpose.
- Never carry out any alterations or modifications to this product.
- This product is intended for indoor use only.
- Do not exceed the 60kg weight limit.
- Keep fingers, loose clothing, and hair away when folding the product.
- Only use this product on stable, level and dry ground.
- Before using the product, make sure all fastenings are tightly in place and that everything is in order, and checked periodically by an adult.
- Make sure that the speaker you place on top of the stand is secure and doesn't pose the risk of falling off easily.
- Leaving the product outside exposed to weather, especially direct sun, rain and salt air, will speed the weathering process. This can be slowed by removing the product from these conditions, or covering it with a suitable cover.
- Clean only with a damp cloth. Do not use strong industrial cleaning substances or abrasive materials as these will damage the product.
- If the product is damaged or has any defects, please contact cservice@oypla.com

Please retain a copy of all instructions for future consultation.



An Official Oypla Branded Product

USER MANUAL Model No: 3496, 3458