

User Manual

Model Code: **4240**, **3502**, **4117**, **4598**

THANK YOU FOR YOUR ORDER

Contents

Front Cover

-

2 Safety
Instructions

-

3 Operating Instructions

-

3 Back Cover

End



Acoustic Guitar

OYPLa

Manual Version: v1.0

Model Code: **4240, 3502, 4117, 4598**

Oypla.com LLP / www.oypla.com

Contents

1 Front Cover

_

2 Safety Instructions

-

3 Operating Instructions

-

3 Back Cover

End

Safety Instructions

Notice: Ensure you read and fully understand instructions before use

While every attempt is made to ensure the highest degree of protection in all equipment, we cannot guarantee freedom from injury. The user assumes all risk of injury due to use. All merchandise is sold on this condition, which no representative of the company can waive or change.

- Make sure that all fastenings are tightly in place and that everything is in order before using the guitar. This should be checked periodically by an adult.
- Do not discard any of the packaging until you have checked that you have all of the parts necessary.
- This product is not a toy, and is only to be used for its designated purpose.
- Keep away from fire.
- Make sure to have a tight hold on the guitar whilst in use.
- This product is only suitable for ages 3+ (varies per model).

- If a child is using this product, they should be supervised at all times.
 - Persons (including children) with reduced physical, sensory and mental capacities or lack of experience and knowledge do not intend this product for use, unless persons responsible for their safety have given them supervision or instruction concerning use of the product.
- If the product is damaged or defective, please contact <u>cservice@oypla.com</u>

Warning

⚠ Do not overtighten strings! Over-tightening can lead to strings snapping.

HAVE A QUESTION ABOUT YOUR PURCHASE?

Our dedicated customer services team are happy to help. Contact them via:

Telephone: 020 3600 22 55

Email: cservice@oypla.com
Live Chat: WWW.OYPLA.COM

Manual Version: v1.0

Model Code: **4240**, **3502**, **4117**, **4598 Oypla.com LLP** / www.oypla.com



Contents

Front Cover

Safety Instructions

3 Operating Instructions

Back Cover 3

End

Operating Instructions

Tuning your new acoustic guitar can be a daunting task if you are not familiar with the process. Below is a QR code link to a handy video to help you.

*Note that any videos included are not property of Oypla.com LLP, and have been created by third parties.



CONSIDER THE ENVIRONMENT!

In the United Kingdom, approximately 5 billion corrugated boxes are used per year, amounting to around 83 per person! By recycling the cardboard box in which this product was packed, you contribute to the preservation and sustainability of the environment.

If you see a recycling logo on the packaging of your product, such as the below examples, that piece of packaging is recyclable. If there is not a recycling logo, please check with your local authorities before recycling.









PLEASE RETAIN A COPY OF THESE INSTRUCTIONS FOR FUTURE CONSULTATION



AN OFFICIAL OYPLA BRANDED PRODUCT

Manual Version: v1.0

Model Code: 4240, 3502, 4117, 4598

