

# LEISURE

THANK YOU FOR YOUR ORDER

## Contents

- 1 Front Cover
- 
- 2 Safety Instructions
- 
- 2 Warnings
- 
- 3 Operating Instructions
- 
- 3 Back Cover

End



## Acoustic Violin Set

## Contents

1	Front Cover
-	
2	Safety Instructions
-	
2	Warnings
-	
3	Operating Instructions
-	
3	Back Cover

End


# Safety Instructions


## Notice: Ensure you read and fully understand instructions before use

While every attempt is made to ensure the highest degree of protection in all equipment, we cannot guarantee freedom from injury. The user assumes all risk of injury due to use. All merchandise is sold on this condition, which no representative of the company can waive or change.

- Make sure all fastenings are tightly in place and that everything is in order before using the product. This should be checked periodically by an adult.
- Do not discard any of the packaging until you have checked that you have all of the parts and fittings required.
- This product is not a toy, and is only to be used for its designated purpose.
- Make sure to have a tight hold of the violin whilst in use.
- This product is suitable for ages of 3+.
- When storing the violin, make sure it is upright and in a safe location where the risk of damage is low.
- We only recommend cleaning the violin with a (mildly) damp cloth. Do NOT use abrasive cleaning chemicals or substances, as these may damage the violin.
- If a child is using this product, they should be supervised at all times.
- Do not carry out alterations or modifications to this product.
- Persons (including children) with reduced physical, sensory and/or mental capacities or lack of experience and knowledge do not intend this product for use, unless persons responsible for their safety have given them supervision or instruction concerning use of the product.
- Keep away from fire.
- If the product is damaged or defective, please contact [cservice@oypla.com](mailto:cservice@oypla.com)

## Warnings

 Do not overtighten strings! Whilst tuning, be wary of overtightening, as doing so may snap the strings.

 Overtightening and incorrect bridge location can lead to damage to the base.

## HAVE A QUESTION ABOUT YOUR PURCHASE?

Our dedicated customer services team are happy to help. Contact them via:

**Telephone:** 020 3600 22 55  
**Email:** [cservice@oypla.com](mailto:cservice@oypla.com)  
**Live Chat:** [WWW.OYPLA.COM](http://WWW.OYPLA.COM)

## Contents

- 1 Front Cover
- 
- 2 Safety Instructions
- 
- 2 Warnings
- 
- 3 Operating Instructions
- 
- 3 Back Cover

End

# Operating Instructions

Setting up your violin for the first time can be a daunting process if you are not familiar with it. Below is a QR link to a helpful video explaining the process in better detail than written instructions can offer.

To view the video, simply open your smartphone camera, aim your camera at the QR code, and a link should appear that you are able to tap on.

\*Please note the below videos are not property of Oypla.com LLP and have been created by independent parties.



## CONSIDER THE ENVIRONMENT!

In the United Kingdom, approximately 5 billion corrugated boxes are used per year, amounting to around 83 per person! By recycling the cardboard box in which this product was packed, you contribute to the preservation and sustainability of the environment.

If you see a recycling logo on the packaging of your product, such as the below examples, that piece of packaging is recyclable. If there is not a recycling logo, please check with your local authorities before recycling.



PLEASE RETAIN A COPY OF THESE INSTRUCTIONS FOR FUTURE CONSULTATION

# OYPLA.COM

AN OFFICIAL OYPLA BRANDED PRODUCT