



COLOUR MAY VARY

Folding Garden Cart

USER MANUAL Model No: 3603, 4031, 4034

Safety Instructions

Notice: Ensure you read and fully understand instructions before use

While every attempt is made to ensure the highest degree of protection in all equipment, we cannot guarantee freedom from injury. The user assumes all risk of injury due to use. All merchandise is sold on this condition, which no representative of the company can waive or change.

- Never exceed the maximum load capacity of 70kg, or it may result in product failure and/or personal injury.
- Be careful when opening and closing the folding wagon, it may cause injury.
- This product is not recommended for the transportation of pets or people.
- Do not leave children unsupervised while using the folding wagon.
- This product contains small parts that could be a choking hazard if swallowed. Keep these items away from children.
- Make sure all fastenings are tightly in place and that everything is in order before using the product. This should be checked periodically by an adult.
- This product is not a toy, and is only to be used for its designated purpose.
- Do not carry out alterations or modifications to this product.
- This product is intended for outdoor use only.
- Leaving the product outside exposed to weather, especially direct sun and rain, will speed the weathering process. This can be slowed by removing the product from these conditions.
- Do not discard any of the packaging until you have checked that you have all of the parts and fittings required.
- Use the correct fixings as indicated. Do not tighten any of the nuts until the unit is completely assembled, then finish by tightening all nuts. All nuts must be tightened before use.
- If the product is damaged or has any defects, please contact cservice@oypla.com

Assembly Instructions


Parts List:

Please check you have all parts below before attempting to assemble this product.

If you are missing any of the below parts, please contact Oypla customer services:

cservice@oypla.com

- A. Plastic Clip [1pc]
- B. Wheels [4pcs]
- C. Frame [1pc]
- D. Canvas Bag [1pc]
- E. Screws/Washers/Nuts [4pcs]
- F. Small Screws [2pcs]



Tools Needed:

Screwdriver

Adjustable wrench

Assembly:

1. Put the wheels into the wheel bracket by using the screws, washers and nuts. Tighten the screw fully and then loosen one half turn for easier wheel movement.
2. Attach the plastic clip to the frame by using the 2x small screws.
3. Place the canvas bag onto the frame.
4. Attach the handle to the middle of the plastic clip.

Note: The handlebar of the canvas bag must be through the iron handle.

Note: To secure the canvas bag, stick the Velcro flaps together.



**Please retain a copy of all instructions for future
consultation.**



An Official Oypla Branded Product

Imported into the EU by Oypla.com LLP, Uxbridge, UB8 2FX

USER MANUAL Model No: 3603, 4031, 4034