

KIDS

THANK YOU FOR YOUR ORDER

Contents

- 1 Front Cover
-
- 2 Safety Instructions
-
- 3 Assembly Instructions
-
- 5 Back Cover

End



Garden Sand Table with Tools

Contents

1	Front Cover
-	-
2	Safety Instructions
-	-
3	Assembly Instructions
-	-
5	Back Cover

End

Safety Instructions

Notice: Ensure you read and fully understand instructions before use

While every attempt is made to ensure the highest degree of protection in all equipment, we cannot guarantee freedom from injury. The user assumes all risk of injury due to use. All merchandise is sold on this condition, which no representative of the company can waive or change.

- This product is only to be used for its designated purpose.
- This product is only suitable for children aged 3 and above.
- Never carry out any alterations or modifications to this product.
- This product is intended for outdoor use only.
- Remove any packaging before giving the toy to a child.
- Children should be supervised by a responsible adult at all times while using this product.
- Leaving the product outside exposed to weather, especially direct sun, rain and salt air, will speed the weathering process. This can be slowed by removing the product from these conditions, or covering it with a suitable cover.
- Clean only with a damp cloth. Do not use strong industrial cleaning substances or abrasive materials, as these will damage the product.
- Only use this product on stable, level and dry ground.
- If the product is damaged or has any defects, please contact cservice@oypla.com.

This product is for children aged 18 months and above!

Contents

1	Front Cover
-	
2	Safety Instructions
-	
3	Assembly Instructions
-	
5	Back Cover

End

Assembly Instructions

Parts List:

- If you are missing any of the below parts, please contact cservice@oypla.com
- Please be aware that you will be referring to this parts list throughout the assembly process.

1. 	2. 	3. 
4. 	5. 	6. 
7. 	8. 	9. 
10. 	<p><u>PART NAMES:</u></p> <p>1. Lid</p> <p>2. Leg x 4</p> <p>3. Watering can</p> <p>4. Sand/Water Table</p> <p>5. Castle Tower</p> <p>6. Fish</p> <p>7. Spade</p> <p>8. Duck</p> <p>9. Fork Digger</p> <p>10. Bridge</p>	

Contents

- 1 Front Cover
-
- 2 Safety Instructions
-
- 3 Assembly Instructions
-
- 5 Back Cover

End

1



To attach the legs (part 2), simply locate the plastic rectangle on each corner on the underside of the sand table (part 4). Simply slide the legs (part 2) over and on to the plastic rectangles, ensuring that they are on in a way that keeps them secured to the underside of the sand table (part 4). Please see the images above. Once done, slowly fill the sand table (part 4) with sand. Do not overfill the sand table (part 4). Below is what the fully assembled garden sand table should look like.



Contents

- 1 Front Cover
-
- 2 Safety Instructions
-
- 3 Assembly Instructions
-
- 5 Back Cover

End



HAVE A QUESTION ABOUT YOUR PURCHASE?

Our dedicated customer services team are happy to help. Contact them via:

Telephone: 020 3600 22 55
Email: cservice@oypla.com
Live Chat: WWW.OYPLA.COM

CONSIDER THE ENVIRONMENT!

In the United Kingdom, approximately 5 billion corrugated boxes are used per year, amounting to around 83 per person! By recycling the cardboard box in which this product was packed, you contribute to the preservation and sustainability of the environment.

If you see a recycling logo on the packaging of your product, such as the below examples, that piece of packaging is recyclable. If there is not a recycling logo, please check with your local authorities before recycling.



PLEASE RETAIN A COPY OF THESE INSTRUCTIONS FOR FUTURE CONSULTATION

OYPLA.COM

AN OFFICIAL OYPLA BRANDED PRODUCT

Manual Version: v1.0

Model Code: 3624

Oypla.com LLP / www.oypla.com