

User Manual

Model Code: 3627

THANK YOU FOR YOUR ORDER

Contents

- Front Cover
 - -
- 2 Safety Instructions
 - -
- 2 Assembly Instructions
 - .
- 3 Back Cover

End



Single Clothes Rail

OYPLa

Manual Version: v1.0 Model Code: 3627

Oypla.com LLP / www.oypla.com

Contents

1 Front Cover

_

2 Safety Instructions

-

2 Assembly Instructions

-

3 Back Cover

End

Safety Instructions

Notice: Ensure you read and fully understand instructions before use

While every attempt is made to ensure the highest degree of protection in all equipment, we cannot guarantee freedom from injury. The user assumes all risk of injury due to use. All merchandise is sold on this condition, which no representative of the company can waive or change.


- This product is not a toy, and is only to be used for its designated purpose.
- Do not allow children or animals to swing
 on, or play with, the product.
- This product is intended for indoor use only.
- Clean only with a damp cloth. Do not use industrial cleaning substances or abrasive materials, as these may damage
 the product.
- Do not carry out alterations or modifications to this product.
- Do not discard any of the packaging until you have checked that you have all the parts and fittings required.
- If the product is damaged or has any defects, please contact cservice@oypla.com
 - Do not exceed the 15kg weight limit.


Assembly Instructions

Parts List:

If you are missing any of the below parts, please contact cservice@oypla.com

Please be aware that you will be referring to this parts list throughout the assembly process.





Oypla.com LLP / www.oypla.com



Contents

1 Front Cover

-

2 Safety Instructions

-

2 Assembly Instructions

_

3 Back Cover

End

Take a base platform and insert two wheels either end, ensuring that they pop into the holes and are secure. Repeat this step with the remaining base platform and two wheels. See the image below.



Push a lower rail pole into the top of the base platform, ensuring it is held tightly in place. Once done, slide the height adjustment cap onto the lower rail pole and untighten the top. After this, lower an upper rail pole into the height adjustment cap and the lower rail pole. When the upper rail pole is at your ideal size, simply tighten the height adjustment cap. Repeat this with the other base platform. Please see the images below.



Push both of the base connection poles into the holes found in the side of the completed base platforms. Once done, push the other completed base platform onto the ends of the base connection poles, ensuring that it is secure once it is in. See the image below.



Attach a corner support onto the top of one of the upper metal poles. Make sure to push it down as far as possible as to avoid it easily becoming loose over time. After this, push the remaining upper metal pole into the corner support. Once done, attach the remaining corner support onto the other end of the upper metal pole and push it down onto the upper metal pole that is inside the height adjustment pole. Please see the image below.



HAVE A QUESTION ABOUT YOUR PURCHASE?

Our dedicated customer services team are happy to help.

Telephone: 020 3600 22 55Email: cservice@oypla.comLive Chat: www.oypla.com

PLEASE RETAIN A COPY OF THESE INSTRUCTIONS FOR FUTURE CONSULTATION

