

Slide the wheel onto the axle, put on the washer and complete by pushing the split pin through the hole in the end of the axle, and bending over to retain.

Ensure axle is clean from dust and dirt to allow free movement of the wheel.

Assembly Instructions



USER MANUAL 600LBS SACK TRUCK - RED Model No: 3683

Safety Instructions

Always load evenly, with the centre of gravity as near the centre and rear of the platform as possible.

Do not exceed the maximum load capacity of 600lbs.


Only use the truck on even ground.

Truck is only to be used for its designated purpose.

Leaving the truck outside exposed to weather, especially direct sun, rain and salt air, will speed with weathering process. This can be slowed by removing the truck from these conditions, or covering it with a suitable cover.

This product includes small parts that could cause choking.





Slide the wheel onto the axle, put on the washer and complete by pushing the split pin through the hole in the end of the axle, and bending over to retain.

Ensure axle is clean from dust and dirt to allow free movement of the wheel.

Assembly Instructions



USER MANUAL 600LBS SACK TRUCK - YELLOW Model No: 3684

Safety Instructions

Always load evenly, with the centre of gravity as near the centre and rear of the platform as possible.

Do not exceed the maximum load capacity of 600lbs.

Only use the truck on even ground.

Truck is only to be used for its designated purpose.

Leaving the truck outside exposed to weather, especially direct sun, rain and salt air, will speed with weathering process. This can be slowed by removing the truck from these conditions, or covering it with a suitable cover.

This product includes small parts that could cause choking.

