



## User Manual

Model Code: 3742/3743

## THANK YOU FOR YOUR ORDER

### Contents

I Front Cover

-

2 Safety Instructions

-

2 Warnings

-

2 Back Cover

End



Sun Lounger

**OYPL**3

Manual Version: v1.0 Model Code: 3742/3743

Oypla.com LLP / www.oypla.com

### Contents

1 Front Cover

-

2 Safety Instructions

Warnings

-

2

2 Back Cover

End

# Safety Instructions

#### Notice: Ensure you read and fully understand instructions before use

While every attempt is made to ensure the highest degree of protection in all equipment, we cannot guarantee freedom from injury. The user assumes all risk of injury due to use. All merchandise is sold on this condition, which no representative of the company can waive or change.

- This product is not a toy, and is only to be used for its designated purpose.
- Never carry out any alterations or modifications.
- This product is intended for outdoor use only.
- Only use this product on stable, level and dry ground.
- Folding/unfolding of this product should only be carried out by a competent adult.
- If the product is damaged or defective, please contact <a href="mailto:cservice@oypla.com">cservice@oypla.com</a>

- Once the chair has been unfolded, ensure it is secure before use.
- Leaving the product outside exposed to weather, especially direct sun, rain and salt air, will speed the weathering process. This can be slowed by removing the product from these conditions.
- Clean only with a damp cloth. Do not use strong industrial cleaning substances or abrasive materials, as these may damage the product.

# Warnings

 $\triangle$  Do not exceed the 100kg weight capacity limit.

⚠ Do not allow children to play on or around the chair. Potential hazard.

A Pinch points cause injury! Keep loose fingers, clothing, jewellery and hair away when folding or unfolding the chair.

#### HAVE A QUESTION ABOUT YOUR PURCHASE?

Our dedicated customer services team are happy to help. Contact them via:

Telephone: 020 3600 22 55
Email: cservice@oypla.com
Live Chat: WWW.OYPLA.COM

### CONSIDER THE ENVIRONMENT!

In the United Kingdom, approximately 5 billion corrugated boxes are used per year, amounting to around 83 per person! By recycling the cardboard box in which this product was packed, you contribute to the preservation and sustainability of the environment.

If you see a recycling logo on the packaging of your product, such as the below examples, that piece of packaging is recyclable. If there is not a recycling logo, please check with your local authorities before recycling.



PLEASE RETAIN A COPY OF THESE INSTRUCTIONS FOR FUTURE CONSULTATION



AN OFFICIAL OYPLA BRANDED PRODUCT

Manual Version: v1.0 Model Code: 3742/3743

Oypla.com LLP / www.oypla.com

