

OYPLATM GARDEN



Artificial Grass

Safety Instructions

Notice: Ensure you read and fully understand instructions before use

While every attempt is made to ensure the highest degree of protection in all equipment, we cannot guarantee freedom from injury. The user assumes all risk of injury due to use. All merchandise is sold on this condition, which no representative of the company can waive or change.

- This product is not a toy, and is only to be used for its designated purpose.
- Never carry out any alterations or modifications to this product.
- Keep the product away from open fires (such as fire pits and barbecues) to avoid the possibility of the artificial grass melting. Reflections from windows, polished gutters, reflective panels and mirrors can also cause the grass to melt.
- Constant exposure to sunlight will cause the colour to fade from the artificial grass. This can be avoided by removing the grass from that environment.
- Clean only with water, such as by hose or even rain. Do not use strong industrial cleaning substances or abrasive materials as these will damage the product.
- This product can be used both indoors and outdoors.
- Before use this product will need flattening. Carefully put weights on all corners until straight.
- If the product is damaged or has any defects, please contact cservice@oypla.com

Please retain a copy of all instructions for future consultation.



An Official Oypla Branded Product

Imported into the EU by Oypla.com LLP, Uxbridge, UB8 2FX

USER MANUAL Model No: 3837