

# OYPLA<sup>TM</sup> HOME



## 2000W Double Hot Plate



# Safety Instructions

**Notice: Ensure you read and fully understand instructions before use**

While every attempt is made to ensure the highest degree of protection in all equipment, we cannot guarantee freedom from injury. The user assumes all risk of injury due to use. All merchandise is sold on this condition, which no representative of the company can waive or change.

- Never carry out any alterations or modifications to this product.
- This product is not a toy, and is only to be used for its designated purpose.
- This product is intended for indoor use only.
- Only use this product on stable, level and dry ground.
- Never leave the appliance unattended when in use.
- The top crystallite surfaces and the heating elements become extremely hot and can cause severe burns. Do not touch these whilst they are hot.
- Make sure the appliance doesn't come into contact with outside sources of heat, such as a cooker top or an open flame.
- To protect against electrical shock, do not immerse cord, plug or any part of this appliance in water or any other liquid.
- Ensure the power supply to the socket into which the appliance is plugged, is in accordance with the rating label on the appliance and that the socket is earthed.
- When the appliance is not in use, always unplug from the mains socket.
- Clean only with a damp cloth. Do not use strong industrial cleaning substances or abrasive materials as these will damage the product. Make sure the product is off, unplugged from the socket and been left for five minutes to remove the risk of electrical shock. Allow for the product to cool down before use.
- If the product is damaged or has any defects, please contact [cservice@oypla.com](mailto:cservice@oypla.com)

## CAUTION!

Do not use pans that are unstable and easily tipped. Use flat-bottomed pans to ensure full contact with the hotplate for maximum heat efficiency.

For long-life performance, avoid dropping any items onto the infrared hotplate.

When using this infrared hotplate for the first time, there will be some smoke, this is normal and safe.


Do not use glass containers!

# Operating Instructions

## Parts List:

If you are missing any of the below parts please contact [cservice@oypla.com](mailto:cservice@oypla.com)

Please be aware that you will be referring to this parts list throughout the assembly



## How to use your Hot Infrared Cooker

Before using your hot infrared hot plate for the first time, turn the hot plate to the highest setting (position 5) for 3 to 5 minutes to protect the coating. This should be done when there is no cooking utensil on the hot plate.

1. Put the hot infrared hotplate on a flat, dry and heat resistant surface.
2. Turn the temperature control dial to off.
3. Put the plug into the power socket
4. Turn the control dial to any desired setting. The unit will cycle on and off to maintain the selected temperature.
5. The indication light at the front of the appliance will turn off when the hot plate reaches the selected temperature, and the procedure of the heating will stop and recycle to maintain the temperature.
6. The heating element will begin to heat immediately. Do not touch while in use, the housing surface will be hot.
7. When not in use, unplug the power cord from the wall outlet and allow it to cool down completely.

### To keep food warmer:

- Turn the knob to "2" to maintain food at a constant warm temperature
- Turn the knob off and food will stay warm for up to 30 minutes as the hot plate gradually cools down.

### Environmental Protection

Products bearing the symbol shown above means that used electrical and electronic equipment (WEEE) should not be mixed with general household waste. For proper treatment, recovery and recycling, please take this product(s) to designated collection points where it will be accepted free of charge. Disposing of this product correctly will help save valuable resources and prevent any potential negative effects on human health and the environment, which could otherwise arise from inappropriate waste handling. Please contact your local authority for further details of your nearest designated collection point. Penalties may be applicable for incorrect disposal of this waste, in accordance with your national legislation.

**Please retain a copy of all instructions for future consultation.**



**An Official Oypla Branded Product**

Imported into the EU by Oypla.com LLP, Uxbridge, UB8 2FX

USER MANUAL Model No: 3838

