



Out of this world savings.

User Manual

Model: **3847**



Shopping Cart

Contents

Safety Information	2
Assembly Instructions.....	3

Safety Information

Please ensure you read and fully understand instructions before use

While every attempt is made to ensure the highest degree of protection in all equipment, we cannot guarantee freedom from injury. The user assumes all risk of injury due to use. All merchandise is sold on this condition, which no representative of the company can waive or change.

- This product should only be used for its designated purpose.
 - Do not carry out alterations or modifications to this product.
 - Leaving the product outside exposed to weather, especially direct sun, rain and salt air, will speed the weathering process. This can be slowed by removing the product from these conditions, or covering it with a suitable cover.
 - Make sure that the bag is secured to the frame correctly before loading items in, this is so that there's no risk of the bag detaching during movement.
 - Clean only with a damp cloth. Do not use strong industrial cleaning substances.
 - Do not discard of any of the packaging until you have checked that you have all of the parts and fittings required.
 - Regularly check the wheels to ensure they are secure, if they are loose, be sure to push them into the spoke.
 - Ensure that the bag is able to close securely with no items overflowing or causing bulges.
 - If the product is damaged or has any defects, please contact cservice@oypla.com.
-

Assembly Instructions

Please refer to the below information to help assemble your Oypla product

If you require assistance with the assembly of your Oypla product, please contact our dedicated team at cservice@oypla.com.

1. Unfold the trolley frame and lay it on the ground.
2. Connect the side tubes using the black holders.
3. Push a wheel onto each of the spokes, making sure that they are secure.
4. Widen the bag and place it into the frame, securing the canvas lid around the frame.

Have a Question About Your Purchase?

Our dedicated customer services team are happy to help. Contact them via:

Telephone: 020 3600 22 55

Email: cservice@oypla.com

Live Chat: www.oypla.com

Consider the Environment!

By recycling the cardboard box in which this product was packed, you contribute towards helping the environment. If you see a recycling logo such as the below on the packaging, it can be recycled. If a recycling logo is not present, please check with your local authority before recycling.



PLEASE RETAIN A COPY OF THESE INSTRUCTIONS FOR FUTURE CONSULTATION

An Official Oypla Branded Product

Imported by Oypla.com LLP, Uxbridge, UB8 2FX

User Manual

Model Code: 3847

Oypla.com LLP / cservice@oypla.com