

User Manual

Model: 3887

Lawn Aerator

User Manual Model Code: 3887 Oypla.com LLP / cservice@oypla.com

Safety Information

Please ensure you read and fully understand instructions before use

While every attempt is made to ensure the highest degree of protection in all equipment, we cannot guarantee freedom from injury. The user assumes all risk of injury due to use. All merchandise is sold on this condition, which no representative of the company can waive or change.

- The aerator is not a toy, and is only to be used for its designated purpose.
- Never carry out any alterations or modifications to the hooks.
- This product is not suitable for use by children.
- Keep any loose hair and clothing away from the aerator when in use, to avoid personal injury.
- Warning! Steel toe-capped boots are recommended due to the nature of the product being operated by foot.

- Clean only with a damp cloth. Do not use abrasive cleaners or detergents.
- If the product is damaged or has any defects, please contact cservice@oypla.com
- Leaving the product outside exposed to weather, especially direct sun, rain and salt air, will speed the weathering process. This can be slowed by removing the product from these conditions, or covering it with a suitable cover.

Have a Question About Your Purchase?

Our dedicated customer services team are happy to help. Contact them via:

Telephone: 020 3600 22 55 Email: cservice@oypla.com Live Chat: www.oypla.com

Consider the Environment

By recycling the cardboard box in which this product was packed, you contribute towards helping the environment. If you see a recycling logo such as the below on the packaging, it can be recycled. If a recycling logo is not present, please check with your local authority before recycling.



PLEASE RETAIN A COPY OF THESE INSTRUCTIONS FOR FUTURE CONSULTATION

An Official Oypla Branded Product Imported by Oypla.com LLP, Uxbridge, UB8 2FX

User Manual Model Code: 3887 Oypla.com LLP / cservice@oypla.com