



Hand Tiller

Safety Instructions

Notice: Ensure you read and fully understand instructions before use

While every attempt is made to ensure the highest degree of protection in all equipment, we cannot guarantee freedom from injury. The user assumes all risk of injury due to use. All merchandise is sold on this condition, which no representative of the company can waive or change.

- Make sure all fastenings are tightly in place and that everything is in order before using the product. This should be checked periodically by an adult.
- This product is intended for outdoor use only.
- This product is not a toy, and is only to be used for its designated purpose.
- Do not carry out alterations or modifications to this product.
- Ensure to use the tiller at a safe distance from your feet to avoid injury.
- Not suitable for use by children.
- Clean only with a damp cloth. Do not use strong industrial cleaning substances.
- Leaving the product outside exposed to weather, especially direct sun and rain, will speed the weathering process. This can be slowed by removing the product from these conditions
- If the product is damaged or has any defects, please contact cservice@oypla.com

Assembly Instructions

1. Insert the upper pole into the tiller head and secure using a nut and bolt.
2. Attach the handle to the assembled body using the remaining two nuts and bolts.



Please retain a copy of all instructions for future consultation.



An Official Oypla Branded Product