



Out of this world savings.

User Manual

Model: **3891**



Golf Club Tubes

Safety Guidelines

Please ensure you read and fully understand instructions before use

While every attempt is made to ensure the highest degree of protection in all equipment, we cannot guarantee freedom from injury. The user assumes all risk of injury due to use. All merchandise is sold on this condition, which no representative of the company can waive or change.

-
- This product is not a toy, and is only to be used for its designated purpose.
 - Never carry out any alterations or modifications to the tubes.
 - This product is intended for use with golf clubs only.
 - Clean the tubes only with a damp cloth. Do not use strong industrial cleaning substances or abrasive materials as these may damage the product.
 - Only use one tube per golf club.
 - If the tubes are damaged or has any defects, please contact cservice@oypla.com
 - Leaving the tubes outside exposed to weather, especially direct sun, rain and salt air, will speed the weathering process. This can be slowed by removing the product from these conditions, or covering it with a suitable cover.
 - Do not expose the tubes to sources of heat.

Have a Question About Your Purchase?

Our dedicated customer services team are happy to help. Contact them via:

Telephone: 020 3600 22 55

Email: cservice@oypla.com

Live Chat: www.oypla.com

Consider the Environment!

By recycling the cardboard box in which this product was packed, you contribute towards helping the environment. If you see a recycling logo such as the below on the packaging, it can be recycled. If a recycling logo is not present, please check with your local authority before recycling.



PLEASE RETAIN A COPY OF THESE INSTRUCTIONS FOR FUTURE CONSULTATION

An Official Oypla Branded Product

Imported by Oypla.com LLP, Uxbridge, UB8 2FX

User Manual

Model Code: 3891

Oypla.com LLP / cservice@oypla.com