



Castle Pop-Up Tent



Safety Instructions

Notice: Ensure you read and fully understand instructions before use

While every attempt is made to ensure the highest degree of protection in all equipment, we cannot guarantee freedom from injury. The user assumes all risk of injury due to use. All merchandise is sold on this condition, which no representative of the company can waive or change.


- This product should only be used for its designated purpose.
- Not suitable for children under 3 years.
- Remove any packaging before giving toy to child.
- Children should be supervised at all times when using the pop-up tent.
- Do not let small children unfold or fold this product.
- Keep away from fire.
- Clean only with a damp cloth. Do not use strong industrial cleaning substances.
- If the product is damaged or has any defects, please contact cservice@oypla.com

Parts List

Fiberglass Poles	4pcs	Tent	1pc	Carry Bag	1pc
------------------	------	------	-----	-----------	-----

Assembly Instructions

1. This product has an internal spring frame that will twist open with some force.
2. Thread fiberglass poles through the appropriate sections in the tent.
3. Make sure you hold it away from your body when unfolding.
4. Follow the easy steps below for folding the product.



An Official Oypla Branded Product

Imported into the EU by Oypla.com LLP, Uxbridge, UB8 2FX

