



User Manual

Model Code: 3907

THANK YOU FOR YOUR ORDER

## Contents

- 1 Front Cover  
-
- 2 Safety  
Instructions  
-
- 2 Warnings  
-
- 2 Assembly  
Instructions  
-
- 4 Back Cover  
-

End



# A1 Sign Frame



## Contents

1	Front Cover
-	-
2	Safety Instructions
-	-
2	Warnings
-	-
2	Assembly Instructions
-	-
4	Back Cover
-	-
	End


# Safety Instructions


## Notice: Ensure you read and fully understand instructions before use

While every attempt is made to ensure the highest degree of protection in all equipment, we cannot guarantee freedom from injury. The user assumes all risk of injury due to use. All merchandise is sold on this condition, which no representative of the company can waive or change.

- Make sure all fastenings are tightly in place, and that everything is in order, before using the product.
- This product is not a toy, and is only to be used for its designated purpose.
- Do not discard any of the packaging until you have checked that you have all of the parts and fittings required.
- Do NOT exceed the maximum capacity of the base which is 26KG. This can lead to product and/or personal injury
- Avoid placing in areas that are exposed to strong winds.
- Only use this product on stable and level ground.
- Do not bend the sign frame over 60 degrees.
- If the product is damaged or defective, please contact [cservice@oypla.com](mailto:cservice@oypla.com)

## Warnings

 Pinch points can cause injury! Keep loose fingers, clothing, jewellery and hair away when closing/opening the frame sides.

 Do not overfill the base with water in the winter. Water may freeze and expand, damaging the product.

# Assembly Instructions

## Parts List:

- If you are missing any of the below parts, please contact [cservice@oypla.com](mailto:cservice@oypla.com)
- Please be aware that you will be referring to this parts list throughout the assembly process.
- Aluminium Frame x1
- Spring x2
- Plastic Base x1
- Bolt x2

Note: the plastic sheets to cover the poster can sometimes be difficult to see, and may need prying out with the end of a knife or other tool.

## Contents

- 1 Front Cover  
-
- 2 Safety  
Instructions  
-
- 2 Warnings  
-
- 2 **Assembly  
Instructions**  
-
- 4 Back Cover  
-

End



- 1** Slide the springs attached to the frame into the base. Lay the product on its side and secure the frame into place using the bolts.



- 2** Open the frame on all four sides, and remove the front screen. Insert the poster(s) into the frame, and replace the screen. Close the frame.



## Contents

- 1 Front Cover
- 
- 2 Safety Instructions
- 
- 2 Warnings
- 
- 2 Assembly Instructions
- 
- 4 Back Cover
- 

End

- 3** After assembly, open the cap on the base and fill with either water or sand. The capacity of the base is 26L. Be careful not to over-fill.



- 4** To move the sign, use the handle on the base to tip the sign onto its wheels.



## HAVE A QUESTION ABOUT YOUR PURCHASE?

Our dedicated customer services team are happy to help. Contact them via:

**Telephone:** 020 3600 22 55  
**Email:** [cservice@oypla.com](mailto:cservice@oypla.com)  
**Live Chat:** [WWW.OYPLA.COM](http://WWW.OYPLA.COM)

## CONSIDER THE ENVIRONMENT!

In the United Kingdom, approximately 5 billion corrugated boxes are used per year, amounting to around 83 per person! By recycling the cardboard box in which this product was packed, you contribute to the preservation and sustainability of the environment.

If you see a recycling logo on the packaging of your product, such as the below examples, that piece of packaging is recyclable. If there is not a recycling logo, please check with your local authorities before recycling.



PLEASE RETAIN A COPY OF THESE INSTRUCTIONS FOR FUTURE CONSULTATION

# OYPLA.COM

AN OFFICIAL OYPLA BRANDED PRODUCT

Imported by Oypla.com LLP, Uxbridge, UB8 2FX

Model Code: 3907

OYPLA

Oypla.com LLP / [www.oypla.com](http://www.oypla.com)