

OYPLA™

HOME

THANK YOU FOR YOUR ORDER



Wall Mounted Washing Line

Safety Instructions

Notice: Ensure you read and fully understand instructions before use

While every attempt is made to ensure the highest degree of protection in all equipment, we cannot guarantee freedom from injury. The user assumes all risk of injury due to use. All merchandise is sold on this condition, which no representative of the company can waive or change.

- Never carry out any alterations or modifications to this product.
- This product is not a toy, and is only to be used for its designated purpose.
- This product is intended for outdoor use only.
- Keep fingers, loose clothing and hair away when folding the product.
- Make sure that the product is in an open space.
- Clean only with a damp cloth. Do not use strong industrial cleaning substances or abrasive materials as these will damage the product.
- If the product is damaged or has any defects, please contact cservice@oypla.com

Assembly Instructions

Parts List:

Please check you have all parts below before attempting to assemble this product.

If you are missing any of the below parts, please contact Oypla customer services:

cservice@oypla.com



4x SCREW

4x WALL PLUGS

WARNING BEFORE DRILLING ANY HOLES INTO A WALL OR SURFACE, ENSURE TO CHECK THE SURFACE USING A STUD DETECTOR TO CHECK THAT THERE ARE NO CABLES OR PIPES PRESENT

1. Using assistance if required, hold the wall mounted washing line against the wall or surface you would like to apply it to. Use a pencil to lightly mark the hole locations before removing the wall mounted washing line, leaving you with 4 light pencil marks on the surface.
2. Proceed to drill the 4 holes into the wall/surface you wish to attach the washing line to, ensuring to use the pencil marks you created as a guideline.
3. Insert a wall plug into each of the four holes, ensuring they are fully inserted.
4. Using assistance if required, line the four holes in the washing line up with the holes, now filled with wall plugs. Using a screwdriver or drill with an appropriate bit, insert the screws into each of the four holes fully. Your wall mounted washing line is now attached.

HAVE A QUESTION ABOUT YOUR PURCHASE?

OUR DEDICATED CUSTOMER SERVICES TEAM ARE HAPPY TO HELP
CONTACT THEM VIA:

TELEPHONE: 020 3600 2255

EMAIL: cservice@oypla.com

LIVE CHAT: www.oypla.com

PLEASE RETAIN A COPY OF THESE INSTRUCTIONS FOR FUTURE CONSULTATION

OYPLA.COM

An Official OYPLA Branded Product

Imported by Oypla.com LLP, Uxbridge, UB8 2FX

USER MANUAL Model No: 3914