



CE

Electric Towel Warmer

Safety Instructions

Notice: Ensure you read and fully understand instructions before use

While every attempt is made to ensure the highest degree of protection in all equipment, we cannot guarantee freedom from injury. The user assumes all risk of injury due to use. All merchandise is sold on this condition, which no representative of the company can waive or change.

- Do not discard any of the packaging until you have checked that you have all of the parts and fittings required.
- This product is not a toy, and is only to be used for its designated purpose.
- Do not carry out any alterations or modifications to this product.
- This product is for domestic use only.
- Clean only with a damp cloth. Do not use strong industrial cleaning substances or abrasive materials as these will damage the product.
- When the appliance is not in use, always unplug from the mains socket.
- Do not use the product near any source of water.
- Do not use the product near flammable materials or liquids.
- To protect against electrical shock, do not immerse cord, plug or any part of this appliance in water or any other liquid.
- Only use this product on stable, level and dry ground.
- Do not lean on the product.
- Keep the product out of the reach of children and pets.
- This product is intended for indoor use only.
- If the product is damaged or has any defects, please contact cservice@oypla.com

⚡ WARNING ⚡

To Reduce The Risk of Fire or Electric Shock, follow these basic precautions:


- Read all instructions before using the electric peeler.
- Never allow children to operate or play with the electric towel warmer.
- Never clean electric towel warmer parts with flammable fluids. The fumes can create a fire hazard or explosion.
- Do not store or use gasoline or any other flammable vapors or liquids in the vicinity of this or any other electric towel warmer. The fumes can create a fire hazard or explosion.

**-Save these
instructions-**

Operating Instructions

Parts List:

If you are missing any of the below parts please contact cservice@oypla.com



Component Parts

A – Tower Rail

B – Support Feet

C – Screws

D – ON/OFF Switch

E – Cable and Plug

1. Assemble the appliance by screwing the feet to the base with the screws provided.
2. Plug the appliance into the wall socket, making sure the power rating is 100W.
3. Switch the ON/OFF switch into the “ON” position – appliance will now begin to heat up.

Care and Maintenance of the Product

1. This appliance needs only an external regular clean. After use and before cleaning always switch the appliance off, disconnect from the power source and wait until it has fully cooled. Clean the bars from dust. For best results use a damp cloth.
2. Once it has fully cooled, store the appliance in a cool, dry place.

Disposal of Unit

Appliances bearing the symbol shown here may not be disposed of in domestic rubbish. You are required to dispose of old electrical and electronic appliances like this separately. Please visit www.recycle-more.co.uk or www.recyclenow.co.uk for access to information about the recycling of electrical items. Please visit www.weeeireland.ie for access to information about the recycling of electrical items purchased in Ireland. The WEEE directive, introduced in August 2006, states that all electrical items must be recycled, rather than taken to landfill, please arrange to take this appliance to your local Civic Amenity site for recycling, once it has reached the end of its life.



Please retain a copy of all instructions for future consultation.



An Official Oypla Branded Product

Imported into the EU by Oypla.com LLP, Uxbridge, UB8 2FX