



Heat Sealer

USER MANUAL Model No: 3959

Safety Instructions

Notice: Ensure you read and fully understand instructions before use

While every attempt is made to ensure the highest degree of protection in all equipment, we cannot guarantee freedom from injury. The user assumes all risk of injury due to use. All merchandise is sold on this condition, which no representative of the company can waive or change.

- The product should only be connected to a 240 V AC, 50 Hz electrical outlet.
- Never leave the product unattended whilst it is switched on.
- If you have to leave the product unattended, even for a short while, always switch it off.
- Keep the product out of children's reach and do not allow children to use it.
- The product is only intended for normal domestic use and only in the manner described in this instruction manual.
- Inspect the mains lead regularly. Never use the product if the mains lead or plug has been damaged in any way.
- Do not place the mains lead on or near any hot surface.
- Do not touch the product if your hands are moist or wet.
- Never move the product by pulling on the lead.
- Do not discard any of the packaging until you have checked that you have all of the parts and fittings required.
- If the product is damaged or has any defects, please contact cservice@oypla.com

WARNING

To Reduce The Risk of Fire or Electric Shock,
follow these basic precautions:

- Read all instructions before using the heat sealer.
- Never allow children to operate or play with the heat sealer.
- Unplug or disconnect this product from the power supply before cleaning.

-Save these instructions-

Operating Instructions

If you are missing any of the below parts please contact

cservice@oypla.com

Please be aware that you will be referring to this parts list throughout the assembly



- | | |
|---------------------|---------------------|
| 1 – Handle | 4 – Operation Light |
| 2 – Sealing Arm | 5 – Timer Knob |
| 3 – Heating Element | 6 – Outer Casing |

1. This machine does not use a power switch. Plug the power cord into the wall socket.
2. Adjust the sealing time according to the thickness of the material to be sealed:
 - **1-2:** 0.1mm
 - **3-4:** 0.2mm
 - **5-6:** 0.3mm
3. Place the plastic bag onto the sealing platform, then push down the handle. The sealer will control the heat time automatically. After the light turns off, release the handle and the seal is completed.
4. If the seal is damaged, it is because the heating time is too long. Reset the timer knob to a lower number.
5. If the plastic bag sticks to the sealing arm, it is because there was not enough cooling time. Keep the arm down for a longer period of time after the light turns off.
6. The unit should always be unplugged when not in use.

Care and Maintenance

1. Always keep the sealing platform clean from any residue. This will reduce the life of the heating element and of the heat-resistant cloth.
2. Do not use any wet cloths to clean the sealing platform.
3. Only use a damp cloth to clean the outer casing of the appliance.
4. Do not use anything other than fresh water to clean the appliance.
5. Only replace the heating element with the same specifications of the original (200mm).
6. Check the cushion when replacing the heating element. If the cushion is broken it will damage the heating element. It should be repaired before using again

Technical Data

Rated Voltage: 240V AC – 50Hz

Power: 300W

Max. Seal Length: 200mm

Max. Seal Thickness: 0.3mm

Seal Width: 2mm

Heating Time: 0.2-1.5s

Weight: 1.4kg

HAVE A QUESTION ABOUT YOUR PURCHASE?

OUR DEDICATED CUSTOMER SERVICES TEAM ARE HAPPY TO HELP
CONTACT THEM VIA:

TELEPHONE: 020 3600 2255

EMAIL: cservice@oypla.com

LIVE CHAT: www.oypla.com

PLEASE RETAIN A COPY OF THESE INSTRUCTIONS FOR FUTURE CONSULTATION



Environmental Protection

Products bearing the symbol shown below means that used electrical and electronic equipment (WEEE) should not be mixed with general household waste. For proper treatment, recovery and recycling, please take this product(s) to designated collection points where it will be accepted free of charge. Disposing of this product correctly will help save valuable resources and prevent any potential negative effects on human health and the environment, which could otherwise arise from inappropriate waste handling. Please contact your local authority for further details of your nearest designated collection point. Penalties may be applicable for incorrect disposal of this waste, in accordance with your national legislation.



OYPLA.COM

An Official OYPLA Branded Product



Imported by Oypla.com LLP, Uxbridge, UB8 2FX

USER MANUAL Model No: 3959