



# Swing Ball Set

USER MANUAL Model No: 3972

# Safety Instructions

**Notice: Ensure you read and fully understand instructions before use**

While every attempt is made to ensure the highest degree of protection in all equipment, we cannot guarantee freedom from injury. The user assumes all risk of injury due to use. All merchandise is sold on this condition, which no representative of the company can waive or change.






- Before using this product, make sure all fastenings are tightly in place and that everything is in order. Check periodically by an adult.
- This product is a toy and should only be used by children of its intended age range.
- Not suitable for children under 36 months.
- This product is intended for indoor use only.
- Do not carry out alterations or modifications to this product.
- Leaving the swing ball set outside exposed to weather, especially direct sun, rain and salt air, will speed the weathering process. This can be slowed by removing the product from these conditions, or covering it with a suitable cover
- Children should be supervised at all times when using this product.
- Clean only with a damp cloth. Do not use strong industrial cleaning substances.
- Players must stand outside the arc of travel to avoid being hit by the ball.
- Do not discard of any packaging until you have checked that you have all of the parts and fittings required.
- This product is for domestic use only.
- Do not discard any of the packaging until you have checked that you have all of the parts and fittings required.
- This product is not intended for use by persons (including children) with reduced physical, sensory and mental capacities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the product by persons responsible for their safety.
- If the product is damaged or has any defects, please contact [cservice@oypla.com](mailto:cservice@oypla.com)

# Operating Instructions

## Parts List:


If you are missing any of the below parts please contact [cservice@oypla.com](mailto:cservice@oypla.com)

Please be aware that you will be referring to this parts list throughout the assembly process.

	Top Pole 1pc		Middle Pole 1pc		Bottom Pole 1pc
2pcs			1pc		

### Stage 1:

Slot the top pole of the swing ball set into the middle pole.



### Stage 2:

Attach the bottom pole to the other side of the middle pole.



### Stage 3:

Tie the rope (with the ball) to the end of the metal pole at the top of the top pole. The rope can be shortened by tying a knot at the top.



**Please retain a copy of all instructions for future consultation.**



**An Official Oypla Branded Product**



Imported into the EU by Oypla.com LLP, Uxbridge, UB8 2FX