

OYPLATM HOME



90cm & 120cm Bubble LED Lights

Safety Instructions

Notice: Ensure you read and fully understand instructions before use

While every attempt is made to ensure the highest degree of protection in all equipment, we cannot guarantee freedom from injury. The user assumes all risk of injury due to use. All merchandise is sold on this condition, which no representative of the company can waive or change.

- This product is not a toy, and is only to be used for its designated purpose.
- Never carry out any alterations or modifications to this product.
- Do not attempt to fill beyond the 'MAX' line, only fill with the designated amount (90cm or 120cm of water).
- **Do not** pull the bubble adjustment screw as this will cause water to leak, creating a safety hazard.
- This product is intended for indoor use only.
- Children should be supervised at all times around this product.
- To protect against electrical shock, do not immerse the cord or plug in water or any other liquid.
- Ensure the power supply to the socket into which the appliance is plugged, is in accordance with the rating label on the appliance and that the socket is earthed.
- Clean only with a damp cloth. Do not use strong industrial cleaning substances or abrasive materials as these will damage the product.
- Unpacking, installing and fixing the parts are to be completed by an adult.
- If the product is damaged or has any defects, please contact cservice@oypla.com

Note:

If the plastic fish remain floating at the top of the lamp or sink straight to the bottom without rising, we recommend washing them lightly using washing detergent – once you have done this, dry them and place them back in the lamp.

KEEP PRODUCT AWAY FROM SOCKETS WHEN IN USE

Operating Instructions

Parts List:

If you are missing any of the below parts please contact cservice@oypla.com

The carton should contain:

- 1x LED Bubble Light Tower
- 1x Assortment of nine coloured fish
- 1x Power cord and plug

How to use the 90cm or 120cm Bubble LED Lights

1. Place the empty LED bubble light tower into an empty space, making sure that electrical appliances and plug sockets aren't in the tower's immediate radius.
2. Take the power cord and insert it into the power component found in the base of the tower (on the opposite side to the bubble adjustment screw. Do not put the plug into a socket at this stage.
3. Remove the lid from the LED bubble light tower and begin to pour water in. Be sure to not exceed the maximum fill limit as this will cause the tower to spill when the bubbles are activated.
4. Once you have filled the LED bubble light tower, you can drop the assortment of coloured fish into the tower. After this, place the lid back onto the tower.
5. Put the plug into an available plug socket, making sure that the plug socket is a reasonable distance from the LED bubble light tower to avoid spillages and potential health and safety hazards.
6. Once the LED bubble light tower is on, turn the bubble adjustment screw to set the rate of which the bubbles come out. Turn right to heighten the amount of bubbles and turn left to lower the amount of bubbles. Do not pull on the bubble adjustment screw as this will cause it to come out and for water to spill, creating a health and safety hazard.



HAVE A QUESTION ABOUT YOUR PURCHASE?

OUR DEDICATED CUSTOMER SERVICES TEAM ARE HAPPY TO HELP
CONTACT THEM VIA:

TELEPHONE: 020 3600 2255

EMAIL: cservice@oypla.com

LIVE CHAT: www.oypla.com

PLEASE RETAIN A COPY OF THESE INSTRUCTIONS FOR FUTURE CONSULTATION



Environmental Protection

OYPLA.COM

An Official OYPLA Branded Product



Products bearing the symbol shown below means that used electrical and electronic equipment (WEEE) should not be mixed with general household waste. For proper treatment, recovery and recycling, please take this product(s) to designated collection points where it will be accepted free of charge. Disposing of this product correctly will help save valuable resources and prevent any potential negative effects on human health and the environment, which could otherwise arise from inappropriate waste handling. Please contact your local authority for further details of your nearest designated collection point. Penalties may be applicable for incorrect disposal of this waste, in accordance with your national legislation.



Imported by Oypla.com LLP, Uxbridge, UB8 2FX

USER MANUAL Model No: 3996/3997 – v2.0