



36W Nail Lamp

USER MANUAL Model No: 4023

User Instructions

Notice: Ensure you read and fully understand instructions before use

While every attempt is made to ensure the highest degree of protection in all equipment, we cannot guarantee freedom from injury. The user assumes all risk of injury due to use. All merchandise is sold on this condition, which no representative of the company can waive or change.

- This product is not a toy, and is only to be used for its designated purpose.
- Never carry out any alterations or modifications to this product.
- Ensure the power supply to the socket into which the appliance is plugged, is in accordance with the rating label on the appliance and that the socket is earthed.
- When the appliance is not in use, always unplug the mains socket.
- To protect against electrical shock, do not immerse cord, plug or any part of this appliance in water or any other liquid.
- If the product is damaged or has any defects, please contact cservice@oypa.com

Operating Instructions

- Wash your hands and nails beforehand, to remove grease and dirt.
- Press the I/O/II switch to position I to turn the UV bulbs on.
- Place your hand or foot into the machine and press the red button in the rear.
- The lamp will turn off automatically after three minutes. However, press the I/O/II switch in to position II to turn the appliance off manually.



Please retain a copy of all instructions for future consultation.