

GARDEN

Model Code: 3603,
4031, 4034

THANK YOU FOR YOUR ORDER

Contents

- 1 Front Cover
-
- 2 Safety
Instructions
-
- 3 Assembly
Instructions
-
- 4 Back Cover

End



Colour May Vary

Folding Garden Cart

Contents

1	Front Cover
-	-
2	Safety Instructions
-	-
3	Assembly Instructions
-	-
4	Back Cover
	End

Safety Instructions

Notice: Ensure you read and fully understand instructions before use

While every attempt is made to ensure the highest degree of protection in all equipment, we cannot guarantee freedom from injury. The user assumes all risk of injury due to use. All merchandise is sold on this condition, which no representative of the company can waive or change.

- Never exceed the maximum load capacity of 70kg, or it may result in product failure and/or personal injury.
- Be careful when opening and closing the folding wagon, it may cause injury.
- This product is not recommended for the transportation of pets or people.
- Do not leave children unsupervised if they are using the folding wagon.
- This product contains small parts that could be a choking hazard if swallowed. Keep these items away from children.
- Make sure all fastenings are tightly in place and that everything is in order before using the product. This should be checked periodically by an adult.
- This product is not a toy, and is only to be used for its designated purpose.
- This product is intended for outdoor use only.
- Only use this product on stable, flat and dry land.
- Do not carry out alterations or modifications to this product.
- Leaving the product outside exposed to weather, especially direct sun and rain, will speed the weathering process. This can be slowed by removing the product from these conditions.
- Do not discard any of the packaging until you have checked that you have all of the parts and fittings required.
- Use the correct fixings as indicated. Do not tighten any of the nuts until the unit is completely assembled, then finish by tightening all nuts. All nuts must be tightened before use.
- If the product is damaged or has any defects, please contact cservice@oypla.com.

Warnings

 Do not exceed the maximum load capacity of 70kg. Overloading, may lead to personal and/or product failure

 This product contains small parts which could be a choking hazard. Keep these parts away from children.

Contents

- 1 Front Cover
-
- 2 Safety Instructions
-
- 3 Assembly Instructions
-
- 4 Back Cover

End

Assembly Instructions


Parts List:

- If you are missing any of the below parts, please contact cservice@oypla.com
- Please be aware that you will be referring to this parts list throughout the assembly process.

- A. **Plastic Clip** [1pc]
- B. **Wheels** [4pcs]
- C. **Frame** [1pc]
- D. **Canvas Bag** [1pc]
- E. **Screws** [4pcs]
- F. **Nuts** [4pcs]
- G. **Small Screws** [2pcs]

Tools Needed:

Screwdriver
Adjustable wrench



1. Unfold the frame and turn it upside down, to allow for easier assembly of the wheels.
2. Put the wheels into the wheel bracket by using the screws and nuts provided. Tighten the screw fully and then loosen one half turn for easier wheel movement. Turn frame back round so the wheels are on the floor.
3. Attach the plastic clip to the centre of the frame by using the 2x small screws.
4. Place the canvas bag onto the frame. The handlebar of the canvas bag must be through the iron handle. To secure the canvas bag, stick the Velcro flaps together.
5. Attach the handle to the middle of the plastic clip.



Contents

- 1 Front Cover
-
- 2 Safety
- Instructions
-
- 3 Assembly
- Instructions
-
- 4 Back Cover

End

HAVE A QUESTION ABOUT YOUR PURCHASE?

Our dedicated customer services team are happy to help. Contact them via:

Telephone: 020 3600 22 55
Email: cservice@oypla.com
Live Chat: WWW.OYPLA.COM

CONSIDER THE ENVIRONMENT!

In the United Kingdom, approximately 5 billion corrugated boxes are used per year, amounting to around 83 per person! By recycling the cardboard box in which this product was packed, you contribute to the preservation and sustainability of the environment.

If you see a recycling logo on the packaging of your product, such as the below examples, that piece of packaging is recyclable. If there is not a recycling logo, please check with your local authorities before recycling.



PLEASE RETAIN A COPY OF THESE INSTRUCTIONS FOR FUTURE CONSULTATION

OYPLA.COM

AN OFFICIAL OYPLA BRANDED PRODUCT
