



A3 Light Box

CE

USER MANUAL Model No: 4040

Safety Instructions

Notice: Ensure you read and fully understand instructions before use

While every attempt is made to ensure the highest degree of protection in all equipment, we cannot guarantee freedom from injury. The user assumes all risk of injury due to use. All merchandise is sold on this condition, which no representative of the company can waive or change.

- The DC adapter should only be connected to a 230V AC, 50Hz electrical outlet.
- Never leave the product unattended whilst it is switched on.
- If you have to leave the product unattended, even for a short time, always switch it off.
- This product is not a toy. Children must be supervised to ensure that they do not play with this product.
- The product is only intended for normal domestic use and only in the manner described in this instruction manual.
- Inspect the power lead regularly. Never use the product if the power lead or plug has been damaged in any way.
- Never move the product by pulling on the lead.
- Do not touch the product if your hands are moist or wet.
- If the product is damaged or has any defects, please contact <u>cservice@oypla.com</u>

Operating Instructions

- Place the light box on a dry, flat working surface.
- Connect to the power by either using the USB cable or the supplied DC power adapter.
- To turn on touch the power button gently and the lighted area will light and gradually brighten.
- To turn off touch the power button again and the lighted area will turn off gradually.
- To adjust the brightness, hold the power button and release your finger at the desired brightness. If you hold the button and the light box is at maximum brightness, it will not brighten any further.

Care and maintenance

Clean the light box surface with a soft cloth and a nonabrasive cleaner if necessary. Never apply cleaner directly onto the light box as it may seep inside the unit.

Please retain a copy of all instructions for future consultation.



An Official Oypla Branded Product

Imported into the EU by Oypla.com LLP, Uxbridge, UB8 2FX

CE



Environmental Protection

Products bearing the symbol shown above means that used electrical and electronic equipment (WEEE) should not be mixed with general household waste. For proper treatment, recovery and recycling, please take this product(s) to designated collection points where it will be accepted free of charge. Disposing of this product correctly will help save valuable resources and prevent any potential negative effects on human health and the environment, which could otherwise arise from inappropriate waste handling. Please contact your local authority for further details of your nearest designated collection point. Penalties may be applicable for incorrect disposal of this waste, in accordance with your national legislation.

USER MANUAL Model No: 4040