

Out of this world savings.

User Manual

Model: 4049



Shopping Cart

Contents

Safety Information	2
What's In The Box?	3
Assembly Instructions	3

Safety Information

Please ensure you read and fully understand instructions before use

While every attempt is made to ensure the highest degree of protection in all equipment, we cannot guarantee freedom from injury. The user assumes all risk of injury due to use. All merchandise is sold on this condition, which no representative of the company can waive or change.

- This product should only be used for its designated purpose.
- Do not carry out alterations or modifications to this product.
- Leaving the product outside exposed to weather, especially direct sun, rain and salt air, will speed the weathering process. This can be slowed by removing the product from these conditions, or covering it with a suitable cover.
- Make sure that the bag is secured to the frame correctly before loading items in, this is so that there's no risk of the bag detaching during movement.

- Clean only with a damp cloth. Do not use strong industrial cleaning substances.
- Do not discard of any of the packaging until you have checked that you have all of the parts and fittings required.
- Regularly check the wheels to ensure they are secure, if they are loose, be sure to push them into the spoke.
- Ensure that the bag is able to close securely with no items overflowing or causing bulges.
- If the product is damaged or has any defects, please contact cservice@oypla.com.

What's In The Box?

Please note that you will be referring to the below parts list during assembly

If any of the below parts are missing or damaged, please contact our dedicated team at cservice@oypla.com.

Part	Quantity
Bag	1
Wheel	2
Steel Frame	1

Assembly Instructions

Please refer to the below information to help assemble your Oypla product

If you require assistance with the assembly of your Oypla product, please contact our dedicated team at cservice@oypla.com.

1. Firstly, the wheels need to be attached. Simply press them onto the poles at the bottom of the frame indicated in the image to the right. They should click into place and may require some force. Make sure to remove the black protector before trying to attach



2. Next, simply unfold the circled bar as seen in the image to the right.



ASSEMBLY INSTRUCTIONS CONTINUE ON THE FOLLOWING PAGE

Oypla.com LLP / cservice@oypla.com

Model Code: 4049

3. Lastly, the bag needs to be attached. Simply pull back the sleeve of the bag over the handle frame as seen in the image below. Then, secure it into place using the Velcro strap.



Have a Question About Your Purchase?

Our dedicated customer services team are happy to help. Contact them via:

Telephone: 020 3600 22 55 Email: cservice@oypla.com Live Chat: www.oypla.com

Consider the Environment!

By recycling the cardboard box in which this product was packed, you contribute towards helping the environment. If you see a recycling logo such as the below on the packaging, it can be recycled. If a recycling logo is not present, please check with your local authority before recycling.



PLEASE RETAIN A COPY OF THESE INSTRUCTIONS FOR FUTURE CONSULTATION

An Official Oypla Branded Product Imported by Oypla.com LLP, Uxbridge, UB8 2FX