

OYPOLEA™

LEISURE



2 Wheel Shopping Trolley

Safety Instructions

Notice: Ensure you read and fully understand instructions before use

While every attempt is made to ensure the highest degree of protection in all equipment, we cannot guarantee freedom from injury. The user assumes all risk of injury due to use. All merchandise is sold on this condition, which no representative of the company can waive or change.

- This product should only be used for its designated purpose.
- Do not carry out alterations or modifications to this product.
- Leaving the product outside exposed to weather, especially direct sun, rain and salt air, will speed the weathering process. This can be slowed by removing the product from these conditions, or covering it with a suitable cover.
- Clean only with a damp cloth. Do not use strong industrial cleaning substances.
- Make sure that the bag is secured to the frame correctly before loading items in, this is so that there's no risk of the bag detaching during movement.
- Do not discard any of the packaging until you have checked that you have all of the parts and fittings required.
- Regularly check the wheels to ensure they are secure, if they are loose, be sure to push them into the spoke.
- Ensure that the bag is able to close securely with no items overflowing or causing bulges.
- If the product is damaged or has any defects, please contact cservice@oypla.com

Operating Instructions

Parts List:

Please be aware that you will be referring to this parts list throughout the assembly process.



Ensure fully assembled and secure before use.

Please retain a copy of all instructions for future consultation.



An Official Oypla Branded Product