



# Lawn Trimmer

# Safety Instructions

## **Notice: Ensure you read and fully understand instructions before use**

While every attempt is made to ensure the highest degree of protection in all equipment, we cannot guarantee freedom from injury. The user assumes all risk of injury due to use. All merchandise is sold on this condition, which no representative of the company can waive or change.

- This product is not a toy, and is only to be used for its designated purpose.
- Never carry out any alterations or modifications to this product.
- This product is intended for outdoor use only.
- This product includes small parts that could cause choking.
- When using the product, use both handles to assure the product remains stable.
- Leaving the product exposed to weather, especially direct sun, rain and salt air, will speed the weathering process. This can be slowed by removing the product from these conditions, or covering it with a suitable cover.
- This product is not intended for use by persons (including children) with reduced physical, sensory and mental capacities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the product by persons responsible for their safety.
- Clean only with a damp cloth. Do not use strong industrial cleaning substances or abrasive materials as these will damage the product.
- If the product is damaged or has any defects, please contact [cservice@oypla.com](mailto:cservice@oypla.com).


# Assembly Instructions

## Parts List:

If you are missing any of the below parts please contact [cservice@oypla.com](mailto:cservice@oypla.com)

Please be aware that you will be referring to this parts list throughout the assembly

Part Name:	Quantity:
Bottom Frame	1
Top Frame	1
Edging Blade	1
Bolt	1
Butterfly Nut	1
Cap Nut	1
Washer	2



## Assembly Instructions:

1. Attach the bottom frame inside the top frame.
2. To secure this in place, push a bolt through the hole and secure it in place using a washer and butterfly nut.
3. Slide the edging blade onto the end of the bottom frame, ensuring that it is all the way down the side pole. Secure this in place using a washer and a cap nut.

## **User Instructions:**

- Wheel the Lawn Edger along the edge of your lawn, whilst doing this the steel blade trims the over-hanging grass as you go along.
- After every use, clean the edging blade with care, Wipe Clean Only.
- For the best results, use the edging cutter against a hard edge such as paving or decking.
- Care and practice may be needed when using against flower beds and also soft edges.

### **HAVE A QUESTION ABOUT YOUR PURCHASE?**

OUR DEDICATED CUSTOMER SERVICES TEAM ARE HAPPY TO HELP  
CONTACT THEM VIA:

**TELEPHONE:** 020 3600 2255

**EMAIL:** [cservice@oypla.com](mailto:cservice@oypla.com)

**LIVE CHAT:** [www.oypla.com](http://www.oypla.com)

PLEASE RETAIN A COPY OF THESE INSTRUCTIONS FOR FUTURE CONSULTATION

# **OYPLA.COM**

An Official OYPLA Branded Product

Imported by Oypla.com LLP, Uxbridge, UB8 2FX

**USER MANUAL Model No: 4051**