

THANK YOU FOR YOUR ORDER

User Manual

Model Code: 4056

Contents

- 1 Front Cover
 - -
- SafetyInstructions
 - _
- 2 Warning
 - -
- 2 Operating
 - Instructions
 - -
- 2 Back Cover

End



Folding Shopping

Cart

OYPLa

Manual Version: v1.0

Model Code: 4056

Oypla.com LLP / www.oypla.com

Contents

Notice: Ensure you read and fully understand instructions before use

Safety Instructions

While every attempt is made to ensure the highest degree of protection in all equipment, we cannot guarantee freedom from injury. The user assumes all risk of injury due to use. All merchandise is sold on this condition, which no representative of the company can waive or

- This product is not a toy, and is only to be used for its designated purpose.
- Never carry out any alterations or modifications to this product.
- Regularly check the wheels to ensure they are secure. If they are loose be sure to push them into the spokes.
- Leaving the product outside exposed to weather, especially direct sun, rain and salt air, will speed the weathering process. This can be slowed by removing the product from these conditions, or covering it with a
- Clean only with a damp cloth. Do not use strong industrial cleaning substances or abrasive materials as these will damage the product.
- If the product is damaged or has any defects, please contact cservice@oypla.com

Front Cover

2 Safety Instructions

Warning

Operating 2 Instructions

Back Cover 2

End

Warning

Never exceed the maximum trolley weight capacity of 25kg.

Operating Instructions




1.Unlatch the side clips.



4.Locate side braces and attach



2. Separate the front and back panels to open the cart



5.Extend handle by pressing button and pulling up.



3. Fold the bottom panel down

HAVE A QUESTION ABOUT YOUR PURCHASE?

Our dedicated customer services team are happy to help. Contact them via:

Telephone: 020 3600 22 55 cservice@oypla.com Live Chat: WWW.OYPLA.COM

CONSIDER THE ENVIRONMENT!

In the United Kingdom, approximately 5 billion corrugated boxes are used per year, amounting to around 83 per person! By recycling the cardboard box in which this product was packed, you contribute to the preservation and sustainability of the

If you see a recycling logo on the packaging of your product, such as the below examples, that piece of packaging is recyclable. If there is not a recycling logo, please check with your local authorities before recycling.





Manual Version: v1.0

Model Code: 4056

