

OYPLA™

GARDEN

THANK YOU FOR YOUR ORDER



3m x 3m Gazebo

Safety Instructions

Notice: Ensure you read and fully understand instructions before use

While every attempt is made to ensure the highest degree of protection in all equipment, we cannot guarantee freedom from injury. The user assumes all risk of injury due to use. All merchandise is sold on this condition, which no representative of the company can waive or change.



- Make sure all fastenings are tightly in place and that everything is in order before using the product. This should be checked periodically by an adult.
- This product is intended for outdoor use only.
- This product is not a toy, and is only to be used for its designated purpose.
- Do not carry out alterations or modifications to this product.
- Leaving the product outside exposed to weather, especially direct sun and rain, will speed the weathering process. This can be slowed by removing the product from these conditions, or covering it with a suitable cover.
- Only use this product on stable, level and dry ground.
- Do not discard any of the packaging until you have checked that you have all of the parts and fitting required.
- Please keep children away when assembling the product.
- Do not use in strong winds.
- Only repack the gazebo when completely dry.
- Keep the gazebo away from screws, staples, hooks, nails etc. to avoid damage to the fabric and frame.
- Do not place the product near lights, gas or electric heaters, candles, fireplaces or any other source of heat, flammable liquids or fire.
- Clean only with a damp cloth. Do not use strong industrial cleaning substances.
- This product is not intended to be used as a permanent structure and should be disassembled and stored away after use.
- Take care when disassembling the product. Follow the steps in reverse order.
- Product will require a minimum of two people to assemble.
- If the product is damaged or has any defects, please contact cservice@oypla.com


Assembly Instructions

Parts List:

If you are missing any of the below parts please contact cservice@oypla.com

Please be aware that you will be referring to this parts list throughout the assembly process.





To attach the 4 wall panels, use the Velcro to secure parts onto the main frame.

HAVE A QUESTION ABOUT YOUR PURCHASE?

Our dedicated customer services team are happy to help. Contact them via:

Telephone: 020 3600 22 55
 Email: cservice@oypla.com
 Live Chat: WWW.OYPLA.COM

CONSIDER THE ENVIRONMENT!

In the United Kingdom, approximately 5 billion corrugated boxes are used per year amounting to around 83 per person! By recycling the cardboard box in which this product was packed, you contribute to the preservation and sustainability of the environment.

If you see a recycling logo on the packaging of your product, such as the below examples, that piece of packaging is recyclable. If there is not a recycling logo, please check with your local authorities before recycling.



PLEASE RETAIN A COPY OF THESE INSTRUCTIONS FOR FUTURE CONSULTATION

OYPLA.COM

AN OFFICIAL OYPLA BRANDED PRODUCT

Imported by Oypla.com LLP, Uxbridge, UB8 2FX

USER MANUAL Model No: 4082