



Out of this world savings.

User Manual

Model: **4101**



Bird Feeding Station

Contents

Safety Information	2
What's In The Box?.....	3
Assembly Instructions.....	4

Safety Information

Please ensure you read and fully understand instructions before use


While every attempt is made to ensure the highest degree of protection in all equipment, we cannot guarantee freedom from injury. The user assumes all risk of injury due to use. All merchandise is sold on this condition, which no representative of the company can waive or change.

- Make sure all fastenings are tightly in place and that everything is in order before using the product. This should be checked periodically by an adult.
 - This product is intended for outdoor use only.
 - This product is not a toy, and is only to be used for its designated purpose.
 - Do not carry out alterations or modifications to this product.
 - Clean only with a damp cloth. Do not use strong industrial cleaning substances.
 - Fill the feeders before attaching to the bird feeding station.
 - **Warning! Never allow children or pets to swing from or play with the feeding station, as doing so may cause injury.**
 - Leaving the product outside exposed to weather, especially direct sun and rain, will speed the weathering process. This can be slowed by removing the product from these direct conditions.
 - Only use this product on stable and level ground.
 - Ensure the product is secure in the ground to avoid injury.
 - Do not discard of any packaging until you have checked that you have all of the parts and fittings required.
 - If the product is damaged or has any defects, please contact cservice@oypla.com.
-

What's In The Box?

Please note that you will be referring to the below parts list during assembly

If any of the below parts are missing or damaged, please contact our dedicated team at cservice@oypla.com.



Assembly Instructions

Please refer to the below information to help assemble your Oypla product

If you require assistance with the assembly of your Oypla product, please contact our dedicated team at cservice@oypla.com.

1. Start with the three main poles. Attach the bottom pole (the one with a ground stake-type bottom) to the middle pole (the one with a hole at each end). Do this using a screw. Then, attach the top pole to the top of the middle pole, also using a screw. When screwed in, cover the screws using the leather screw covers provided.
2. Next, add the hangers at the top of the pole. The two sets of two hangers should fit together snug – the wing nuts should be on the same corner (align vertically) when they are put together correctly. Loosen the wingnuts to allow them to secure onto the pole. Once together, apply the hangers onto the top pole, until they reach the ring. Please see the below image for help. Tighten the wingnuts to secure the fitting.




3. Next, apply the food and water bowls. The food bowl already has a ring welded, but the water bowl (plastic) has a separate ring. To attach the rings, please follow the below image instructions.


Approach from a
sideward angle




Wrap it around the
central pole



Tilt upwards and then
push downward



-
- Then, assemble the plastic and metal tubes (feeders) by screwing the notches into the corresponding gaps in the tops and bottoms. The tops are the domed sides with the hooks. NOTE! The plastic tubes have holes at one end of the tube, this is intended to be the bottom of the feeder, to allow food to naturally fall out onto the bottom.



- Finally, all that is left to do is to hang the feeders onto the hooks when they are ready to use. The spare ring can be used to attach an extra feeder of your choice should you desire to do so.



Have a Question About Your Purchase?

Our dedicated customer services team are happy to help. Contact them via:

Telephone: 020 3600 22 55

Email: cservice@oypla.com

Live Chat: www.oypla.com

Consider the Environment!

By recycling the cardboard box in which this product was packed, you contribute towards helping the environment. If you see a recycling logo such as the below on the packaging, it can be recycled. If a recycling logo is not present, please check with your local authority before recycling.



PLEASE RETAIN A COPY OF THESE INSTRUCTIONS FOR FUTURE CONSULTATION

An Official Oypla Branded Product

Imported by Oypla.com LLP, Uxbridge, UB8 2FX

User Manual

Model Code: 4101

Oypla.com LLP / cservice@oypla.com