



3pc Skillet Set

USER MANUAL Model No: 4157

Safety Instructions

Notice: Ensure you read and fully understand instructions before use

While every attempt is made to ensure the highest degree of protection in all equipment, we cannot guarantee freedom from injury. The user assumes all risk of injury due to use. All merchandise is sold on this condition, which no representative of the company can waive or change.

- Before first use, apply vegetable oil to the surface of the skillet and pre-heat slowly (start on a low temperature and slowly increase the temperature).
- Once the skillet has been pre-heated it is ready for use.
- After use, clean the skillet with a stiff nylon brush and hot water. Do not use soap or detergents as this may damage the non-stick coating. This product is not dishwasher safe.
- Towel dry immediately after cleaning and apply a light coating of oil while the stone is still warm. Do not let the skillet air dry as this may cause rusting. Store the skillet in a cool, dry place.
- Remember that the handle will become very hot during use. Always use oven gloves to prevent burns while moving or handling the skillet.
- This product is not a toy and should only be used for its designated purpose.
- If the product is damaged or has any defects, please contact cservice@oypla.com

HAVE A QUESTION ABOUT YOUR PURCHASE?

OUR DEDICATED CUSTOMER SERVICES TEAM ARE HAPPY TO HELP
CONTACT THEM VIA:

TELEPHONE: 020 3600 2255

EMAIL: cservice@oypla.com

LIVE CHAT: www.oypla.com

PLEASE RETAIN A COPY OF THESE INSTRUCTIONS FOR FUTURE CONSULTATION

OYPLA.COM

An Official OYPLA Branded Product

Imported by Oypla.com LLP, Uxbridge, UB8 2FX

USER MANUAL Model No: 4157