

DIY

User Manual

Model Code: 4201

THANK YOU FOR YOUR ORDER

Contents

- 1 Front Cover
-
- 2 Safety Instructions
-
- 3 Warnings
-
- 4 Additional Information
-
- 4 Back Cover

End



2-Step Step Stool

Contents

Safety Instructions

Notice: Ensure you read and fully understand instructions before use

While every attempt is made to ensure the highest degree of protection in all equipment, we cannot guarantee freedom from injury. The user assumes all risk of injury due to use. All merchandise is sold

| | |
|---|------------------------|
| 1 | Front Cover |
| - | - |
| 2 | Safety Instructions |
| - | - |
| 3 | Warnings |
| - | - |
| 4 | Additional Information |
| - | - |
| 4 | Back Cover |

End

- This product is not a toy, and is only to be used for its designated purpose.
- Never carry out any alterations or modifications to this product.
- Do not move the ladder whilst standing on it.
- For outdoor use, use caution to the wind.
- Do not overload the stool.
- Make sure to distribute weight evenly on the stool.
- Do not spent long periods of time on a stool without regular breaks. Tiredness is a risk.
- Prevent damage to the stool when transporting e.g. by fastening and, ensure they are suitably placed to prevent damage.
- Ensure the stool is suitable for the task at hand.
- When positioning the stool, take into account the risk of collision with the stool e.g. from pedestrians, vehicles, or doors. Secure doors (not fire exits) and windows where possible in the work area.
- Warning, electricity hazard. Identify any electrical risks in the work area, such as overhead lines or other exposed electrical equipment, and do not use the ladder where electrical risks occur.
- Never use the stool on uneven ground.
- Keep your body centred and do not over reach, as this will increase the chance of falling and injury.
- Keep fingers, loose clothing, hair and jewellery away when folding/unfolding the stool.
- This product is not suitable for use by children.
- Leaving the stool outside and exposed to weather, especially direct sunlight, rain and salt air, will speed the weathering process. This can be slowed by removing the product from these conditions, or covering the product with a suitable cover.
- Do not use the stool if contaminated, e.g. with wet paint, mud, oil or snow.
- Do not use the stool outside in adverse weather conditions, such as strong wind.
- Use non-conductive ladders for unavoidable live electrical work.
- Any horizontal surface which looks like a platform on a standing stool that is not designed for standing on, shall be clearly indicated on that surface,
- If the stool is damaged or defective, please contact cservice@oypla.com

Contents

- 1 Front Cover
-
- 2 Safety Instructions
-
- 3 Warnings
-
- 4 Additional Information
-
- 4 Back Cover

End

Warnings



Warning, fall from the ladder.



Keep a secure grip on the ladder when ascending and descending. Maintain a handhold whilst working from a ladder or take additional safety precautions if you cannot.



Refer to instruction manual/booklet



Avoid work that imposes a sideways load on ladders, such as side-on drilling through solid materials.




Inspect the ladder after delivery. Before every use visually check the ladder is not damaged and is safe to use. Do not use a damaged ladder.



Do not carry equipment which is heavy or difficult to handle while using a ladder.



Maximum total load



Do not wear unsuitable footwear when climbing a ladder.



Do not use the ladder on a uneven or infirm base.



Do not use the ladder if you are not fit enough. Certain medical conditions or medication, alcohol or drug abuse could make ladder use unsafe.



Do not overreach.



Do not use the ladder as a bridge.



Do not erect ladder on contaminated ground.



Ladder for domestic use.



Maximum number of users.



Do not step off the side of standing ladder onto another surface.



Do not ascend or descend unless you are facing the ladder.



Open the ladder fully before use.



Warning, electricity hazard Identify any electrical risks in the work area, such as overhead lines or other exposed electrical equipment and do not use the ladder where electrical risks occur.



Use the ladder with restraint devices engaged only.



Do not stand on the top two steps/rungs of a standing ladder without a platform and a hand/knee rail.



Standing ladders shall not be used as a leaning ladder unless it is designed to do so.

EN ISO 7010-W012



Contents

| | |
|---|------------------------|
| 1 | Front Cover |
| - | - |
| 2 | Safety Instructions |
| - | - |
| 3 | Warnings |
| - | - |
| 4 | Additional Information |
| - | - |
| 4 | Back Cover |

End

Note: regular inspections should be conducted. For the regular inspection, the following items shall be taken into account:

- Check that the stiles/legs (uprights) are not bent, bowed, twisted, dented, cracked, corroded or rotten.
- Check that the stiles/legs around the fixing points for other components are in good condition.
- Check that fixings (usually rivets, screws or bolts) are not missing, loose, or corroded.
- Check that rungs/steps are not missing, loose, excessively worn, corroded or damaged.
- Check that the hinges between front and rear sections are not damaged, loose or corroded.
- Check that the locking stays horizontal, back rails and corner braces are not missing, bent, loose, corroded or damaged.
- Check that the rung hooks are not missing, damaged, loose or corroded and engage properly on the rungs.
- Check that the guide brackets are not missing, damaged, loose or corroded and engage properly on the mating.
- Check that ladder feet / end caps are not missing, loose, excessively worn, corroded or damaged.
- Check that the entire ladder is free from contaminants (e.g. dirt, mud, paint, oil or grease).
- Check that locking catches (if fitted) are not damaged or corroded and function correctly.
- Check that the platform (if fitted) has no missing parts or fixings and is not damaged or corroded.
- If any of the above checks cannot be fully satisfied, you should NOT use the ladder.

For special ladder types, further items identified by the manufacturer shall be taken into account

HAVE A QUESTION ABOUT YOUR PURCHASE?

Our dedicated customer services team are happy to help. Contact them via:

Telephone: 020 3600 22 55
Email: cservice@oypla.com
Live Chat: WWW.OYPLA.COM

CONSIDER THE ENVIRONMENT!

In the United Kingdom, approximately 5 billion corrugated boxes are used per year, amounting to around 83 per person! By recycling the cardboard box in which this product was packed, you contribute to the preservation and sustainability of the environment.

If you see a recycling logo on the packaging of your product, such as the below examples, that piece of packaging is recyclable. If there is not a recycling logo, please check with your local authorities before recycling.



PLEASE RETAIN A COPY OF THESE INSTRUCTIONS FOR FUTURE CONSULTATION

OYPLA.COM

AN OFFICIAL OYPLA BRANDED PRODUCT