



10L Soup Kettle




Safety Instructions

Notice: Ensure you read and fully understand instructions before use

While every attempt is made to ensure the highest degree of protection in all equipment, we cannot guarantee freedom from injury. The user assumes all risk of injury due to use. All merchandise is sold on this condition, which no representative of the company can waive or change.

- This product is intended for indoor use only.
- Do not carry out alterations or modifications to this product.
- To protect against electrical shock, do not immerse cord, plug or any part of this appliance in water or any other liquid.
- Never operate electrical appliance in immediate vicinity of water sources.
- Ensure the power supply to the socket into which the appliance is plugged, is in accordance with the rating label on the appliance and that the socket is earthed.
- When the appliance is not in use, always unplug from the mains socket.
- This product must only be used on a level surface.
- Do not leave this kettle unattended when in use.
- Do not operate the kettle while it is empty.
- Do not fill the kettle up to the top and make sure that you do not overfill the kettle. Remove any excess water before use.
- Never move or carry the kettle when it is 'ON' or if it is full of hot liquids.
- Be careful to not touch any of the hot surfaces of the kettle and make sure that the cord isn't in contact with any hot surfaces.
- Any spilled food on the exterior of the soup kettle should be cleaned immediately with a soft, damp cloth.
- The stainless steel soup container is washable.
- The soup kettle is not designed to cook soups or sauces or to re-heat cold or frozen products.
- Always keep the hinged lid attached and closed when not serving.
- If the product is damaged or has any defects, please contact cservice@oypla.com

Operating Instructions



Parts:

- 1 Lid
- 2 Soup kettle body
- 3 Power Indicator Lamp
- 4 Temperature Controller
- 5 Temperature Indicator Lamp
- 6 Aluminium water tank
- 7 Stainless steel soup container

To change the temperature of the kettle, turn the temperature controller between ranges 1-3 and the indicator light will glow to show that the kettle is on. When the product is off, the light will not glow. When temperature is set to 3 it is at a high temperature.

Capacity: 10 litres	Current: 220V/400W
Weight: 5.50kg	Size: 35 x 35 x 38cm

Please retain a copy of all instructions for future consultation.



An Official Oypla Branded Product

Imported into the EU by Oypla.com LLP, Uxbridge, UB8 2FX



Environmental Protection

Products bearing the symbol shown above means that used electrical and electronic equipment (WEEE) should not be mixed with general household waste. For proper treatment, recovery and recycling, please take this product(s) to designated collection points where it will be accepted free of charge. Disposing of this product correctly will help save valuable resources and prevent any potential negative effects on human health and the environment, which could otherwise arise from inappropriate waste handling. Please contact your local authority for further details of your nearest designated collection point. Penalties may be applicable for incorrect disposal of this waste, in accordance with your national legislation.

USER MANUAL Model No: 4218