

OYPLA™
GARDEN

THANK YOU FOR YOUR ORDER



Folding Picnic Table

Safety Instructions




Notice: Ensure you read and fully understand instructions before use

While every attempt is made to ensure the highest degree of protection in all equipment, we cannot guarantee freedom from injury. The user assumes all risk of injury due to use. All merchandise is sold on this condition, which no representative of the company can waive or change.

- Before using the table, make sure that all fastenings are tightly in place and that everything is in order, and check periodically.
- This table is only suitable for a maximum of 4 users at a time.
- Only sit on the designated seating areas.
- Keep fingers, loose clothing and hair away when folding the table.
- The maximum user weight for each chair should not exceed 100kg.
- The maximum weight on the table top should not exceed 30kg.
- This product is not a toy, and is only to be used for its designated purpose.
- Leaving the product outside exposed to weather, especially direct sun, rain and salt air, will speed the weathering process. This can be slowed by removing the product from these conditions, or covering it with a suitable cover.
- Do not discard of any packaging until you have checked that you have all of the parts and fittings required.
- If the product is damaged or has any defects, please contact cservice@oypla.com



- To open, lift up lock buttons, to close, press end of handles together.
- After opening the case, pull out leg frames and fix support arms with bolting slide.
- After fixing leg frames, push the safety level until you hear 'click'.
- To close, move the safety level in opposite direction.
- When both seats are firmly fixed, set the table right side and insert the security nails in lateral sides of the table.
- Check and fasten the screws regularly.



HAVE A QUESTION ABOUT YOUR PURCHASE?

Our dedicated customer services team are happy to help. Contact them via:

Telephone: 020 3600 22 55
Email: cservice@oypla.com
Live Chat: WWW.OYPLA.COM

CONSIDER THE ENVIRONMENT!

In the United Kingdom, approximately 5 billion corrugated boxes are used per year amounting to around 83 per person! By recycling the cardboard box in which this product was packed, you contribute to the preservation and sustainability of the environment.

If you see a recycling logo on the packaging of your product, such as the below examples, that piece of packaging is recyclable. If there is not a recycling logo, please check with your local authorities before recycling.



PLEASE RETAIN A COPY OF THESE INSTRUCTIONS FOR FUTURE CONSULTATION

OYPLA.COM

AN OFFICIAL OYPLA BRANDED PRODUCT

Imported by Oypla.com LLP, Uxbridge, UB8 2FX

USER MANUAL Model No: 3910