

OYPLA™

GARDEN

THANK YOU FOR YOUR ORDER



Handheld Spreader

Safety Instructions

Notice: Ensure you read and fully understand instructions before use

While every attempt is made to ensure the highest degree of protection in all equipment, we cannot guarantee freedom from injury. The user assumes all risk of injury due to use. All merchandise is sold on this condition, which no representative of the company can waive or change.

- Do not fill overfill.
- This spreader is not a toy, and is only to be used for its designated purpose.
- Leaving the product outside exposed to weather, especially direct sun, rain and salt air, will speed the weathering process. This can be slowed by removing the product from these conditions, or covering it with a suitable cover.
- Keep fingers, hair and loose clothing free from moving parts at all times
- Do not use during strong winds as this may affect the spreading pattern.
- Never leave contents in the spreader. After each use, wash thoroughly to remove all contents. Hot water may be required at times to remove stubborn residue. It is important to allow the spreader to dry thoroughly.
- Ensure that the material is dry and free-running. If in doubt pass it through a sieve with 3mm mesh to remove lumps.
- Store the spreader in a clean, dry space.
- If the product is damaged or has any defects, please contact cservice@oypla.com

Operating Instructions

1. To fill, place the spreader on a level surface. Do not fill directly on a lawn or cultivated area.
2. Adjust the setting of the spreader using the slider on the right-hand side of the trigger.
3. To apply, hold the spreader at a comfortable height, pull the trigger and walk normally whilst turning the handle.
4. Application rates can vary depending on crank and walking speed. To increase application rate, overlap more frequently.

HAVE A QUESTION ABOUT YOUR PURCHASE?

Our dedicated customer services team are happy to help. Contact them via:

Telephone: 020 3600 22 55
Email: cservice@oypla.com
Live Chat: WWW.OYPLA.COM

CONSIDER THE ENVIRONMENT!

In the United Kingdom, approximately 5 billion corrugated boxes are used per year amounting to around 83 per person! By recycling the cardboard box in which this product was packed, you contribute to the preservation and sustainability of the environment.

If you see a recycling logo on the packaging of your product, such as the below examples, that piece of packaging is recyclable. If there is not a recycling logo, please check with your local authorities before recycling.



PLEASE RETAIN A COPY OF THESE INSTRUCTIONS FOR FUTURE CONSULTATION

OYPLA.COM

AN OFFICIAL OYPLA BRANDED PRODUCT

Imported by Oypla.com LLP, Uxbridge, UB8 2FX

USER MANUAL Model No: 4306