

HOME

THANK YOU FOR YOUR ORDER



*COLOUR MAY VARY

Dish Drainer

USER MANUAL Model No: 4603/4604

Safety Instructions

Notice: Please read all instructions carefully before using this product.

- This product is not a toy, and is only to be used for its designated purpose.
- This product is intended for indoor use only.
- Clean only with a damp cloth. Do not use abrasive cleaners or detergents.
- Do not overload the product.
- The user is responsible for ensuring that the product is not overloaded.
- If the product is damaged or has any defects, please contact cservice@oypla.com

HAVE A QUESTION ABOUT YOUR PURCHASE?

Our dedicated customer services team are happy to help. Contact them via:

Telephone: 020 3600 22 55
Email: cservice@oypla.com
Live Chat: WWW.OYPLA.COM

CONSIDER THE ENVIRONMENT!

In the United Kingdom, approximately 5 billion corrugated boxes are used per year amounting to around 83 per person! By recycling the cardboard box in which this product was packed, you contribute to the preservation and sustainability of the environment.

If you see a recycling logo on the packaging of your product, such as the below examples, that piece of packaging is recyclable. If there is not a recycling logo, please check with your local authorities before recycling.



PLEASE RETAIN A COPY OF THESE INSTRUCTIONS FOR FUTURE CONSULTATION

OYPLA.COM

AN OFFICIAL OYPLA BRANDED PRODUCT

USER MANUAL Model No: 4603/4604