

OYPLATM GARDEN



Parasol

USER MANUAL Model No: 4078

Safety Instructions

Notice: Please read all instructions carefully before using this product.

- Make sure all fastenings are tightly in place and that everything is in order before using the product. This should be checked periodically by an adult.
- This product is intended for outdoor use only.
- This product is not a toy, and is only to be used for its designated purpose.
- Umbrella ribs may compress during shipping. To avoid permanent damage, before opening the parasol, turn it upside down and shake gently to separate the ribs into their natural open position. Carefully turn the parasol upright and secure into your parasol base.
- If using the parasol with a table, make sure the plastic parasol ring is inserted into the hole in the centre of the table before placing the parasol through the opening and into an appropriate parasol base.
- Clean only with a damp cloth. Do not use strong industrial cleaning substances.
- Leaving the product outside exposed to weather, especially direct sun and rain, will speed the weathering process. This can be slowed by removing the product from these conditions, or covering it with a suitable cover.
- Do not use the parasol in windy or stormy weather.
- Watch out for any nearby obstacles when opening the parasol.
- Do not use the parasol without an appropriate parasol base.
- If the product is damaged or has any defects, please contact cservice@oypla.com

HAVE A QUESTION ABOUT YOUR PURCHASE?

OUR DEDICATED CUSTOMER SERVICES TEAM ARE HAPPY TO HELP
CONTACT THEM VIA:

TELEPHONE: 020 3600 2255

EMAIL: cservice@oypla.com

LIVE CHAT: www.oypla.com

PLEASE RETAIN A COPY OF THESE INSTRUCTIONS FOR FUTURE CONSULTATION

OYPLA.COM

An Official OYPLA Branded Product

Imported by Oypla.com LLP, Uxbridge, UB8 2FX

USER MANUAL Model No: 4078