



User Manual

Model Code: 4672

THANK YOU FOR YOUR ORDER

Contents

- I Front Cover
 - -
- 2 Safety
 Instructions
 - -
- 3 Operating Instructions
- 4 Back Cover

End



9pc Corkscrew Set

OYPLa

Manual Version: v1.0

Model Code: **4672**

Oypla.com LLP / www.oypla.com

Contents

1 Front Cover

-

2 Safety Instructions

-

3 Operating Instructions

-

4 Back Cover

End

Safety Instructions

Notice: Ensure you read and fully understand instructions before use

While every attempt is made to ensure the highest degree of protection in all equipment, we cannot guarantee freedom from injury. The user assumes all risk of injury due to use. All merchandise is sold on this condition, which no representative of the company can waive or change.

- Please wash products before use.
- Do not microwave.
- Do not discard any of the packaging until you have checked that you have
 all of the parts required.
- This product is for domestic use only.
- This product contains sharp parts. Do
 not let children near these items and
 be careful not to cause personal
 injury.
- This product is not a toy, and is only to be used for its designated purpose.
- Do not allow children to play with or operate the product or any of its components.
- If the product is damaged or has any defects, please contact <u>cservice@oypla.com</u>

Warnings

⚠ This product contains sharp parts that can cause personal injury. Keep away from children.

Corkscrew Operating Instructions



Use the foil cutter to remove any foil seal around the cork.



 The spiral should be driven fully into the cork.



 Swing the lever to the fully open position and put the opener over the bottle. Grip the bottle neck firmly with the grip handles.



3) Keep a firm grip on the bottle neck with the handles, and slowly bring the lever up to the closed position.



Slowly lift the lever back to the opened position.



6) The cork should now have been pulled out of the bottle successfully.

Manual Version: v1.0 Model Code: 4672

Oypla.com LLP / www.oypla.com



Contents

1 Front Cover

-

2 Safety Instructions

-

3 Operating Instructions

-

4 Back Cover

End

HAVE A QUESTION ABOUT YOUR PURCHASE?

Our dedicated customer services team are happy to help. Contact them via:

Telephone: 020 3600 22 55
Email: cservice@oypla.com
Live Chat: WWW.OYPLA.COM

CONSIDER THE ENVIRONMENT!

In the United Kingdom, approximately 5 billion corrugated boxes are used per year, amounting to around 83 per person! By recycling the cardboard box in which this product was packed, you contribute to the preservation and sustainability of the

If you see a recycling logo on the packaging of your product, such as the below examples, that piece of packaging is recyclable. If there is not a recycling logo, please check with your local authorities before recycling.









PLEASE RETAIN A COPY OF THESE INSTRUCTIONS FOR FUTURE CONSULTATION



AN OFFICIAL OYPLA BRANDED PRODUCT

Manual Version: v1.0

Model Code: 4672

Oypla.com LLP / www.oypla.com

