



Out of this world savings.

User Manual

Model: **4672**



Wine Accessory Set

Safety Information

Please ensure you read and fully understand instructions before use

While every attempt is made to ensure the highest degree of protection in all equipment, we cannot guarantee freedom from injury. The user assumes all risk of injury due to use. All merchandise is sold on this condition, which no representative of the company can waive or change.

- Please wash products before use.
 - Do not microwave.
 - Do not discard any of the packaging until you have checked that you have all of the parts required.
 - This product is for domestic use only.
 - This product contains sharp parts. Do not let children near these items and be careful not to cause personal injury.
 - This product is not a toy, and is only to be used for its designated purpose.
 - Do not allow children to play with or operate the product or any of its components.
 - If the product is damaged or has any defects, please contact cservice@oypla.com
 - **Warning! This product contains sharp parts that can cause personal injury. Keep away from children and pets.**
-

Corkscrew Operating Instructions

**STEP 1**

1) Use the foil cutter to remove any foil seal around the cork.

**STEP 2**

2) Swing the lever to the fully open position and put the opener over the bottle. Grip the bottle neck firmly with the grip handles.

**STEP 3**

3) Keep a firm grip on the bottle neck with the handles, and slowly bring the lever up to the closed position.

**STEP 4**

4) The spiral should be driven fully into the cork.

**STEP 5**

5) Slowly lift the lever back to the opened position.

**STEP 6**

6) The cork should now have been pulled out of the bottle successfully.

Have a Question About Your Purchase?

Our dedicated customer services team are happy to help. Contact them via:

Telephone: 020 3600 22 55
Email: cservice@oypla.com
Live Chat: www.oypla.com

Consider the Environment!

By recycling the cardboard box in which this product was packed, you contribute towards helping the environment. If you see a recycling logo such as the below on the packaging, it can be recycled. If a recycling logo is not present, please check with your local authority before recycling.



PLEASE RETAIN A COPY OF THESE INSTRUCTIONS FOR FUTURE CONSULTATION

An Official Oypla Branded Product

Imported by Oypla.com LLP, Uxbridge, UB8 2FX

User Manual

Model Code: 4672

Oypla.com LLP / cservice@oypla.com