

User Manual

Model Code: **4748/4749**

Contents

- 1 Front Cover
- 2 Safety Instructions
- 3 Assembly Instructions
- 3 Operating Instructions
- 4 Back Cover



Bedside Lamp

Manual Version: V1.0 Model Code: 4748/4749

Contents

- 1 Front Cover
- 2 <u>Safety</u> <u>Instructions</u>
- 3 Assembly Instructions
- 3 Operating Instructions
- 4 Back Cover

Safety Instructions

Notice: Ensure you read and fully understand instructions before use

While every attempt is made to ensure the highest degree of protection in all equipment, we cannot guarantee freedom from injury. The user assumes all risk of injury due to use. All merchandise is sold on this condition, which no representative of the company can waive or change.

- This product is not a toy, and is only to be used for its designated purpose.
- Never carry out alterations or modifications to this product.
- This product is intended for indoor use only.
- Do not use this product if the power cable is damaged. Return the product.
- To protect against electrical shock, do not immerse the cable or any part of this appliance in water or any other liquid.
- Do not leave the product on for extended periods of time as this will cause the bulb to become hot and may decrease the overall lifespan of the bulb.
- Clean only with a damp cloth. Do not use strong industrial cleaning substances or abrasive materials as these will damage the product. Make sure the product is switched off and has been unplugged from the port before you clean the product.
- If the product is damaged or has any defects, please contact cservice@oypla.com
- Allow a minimum of 10 minutes to cool before replacing, adjusting or cleaning the product.
- Do not look directly at the light.
- Keep lamp away from materials that may burn.
- Ensure the product is switched off at the rocker switch before installing.
- Check that the product is in good condition and has no defects before installing.

Manual Version: V1.0 Model Code: 4748/4749



Contents

- 1 Front Cover
- 2 Safety Instructions
- 3 <u>Assembly</u> <u>Instructions</u>
- 3 <u>Operating</u> <u>Instructions</u>
- 4 Back Cover

Assembly Instructions



Operating Instructions

- When the rocker switch (the switch on the cord) is in the ON position, the pull chain can be used to switch the lamp on or off.
- If you wish to charge a phone or device using the lamp's USB port, simply connect the charging cable to the USB port.
- Turning the rocker switch to the OFF position will turn off the lamp's power supply and also the USB port's power supply.

Manual Version: V1.0 Model Code: 4748/4749

Contents

1 Front Cover

2 Safety Instructions

3 Assembly Instructions

3 Operating Instructions

4 Back Cover

Technical Information

Voltage: 85-265V

- Power Source: Corded/Electric

- Material: Wood/Fabric

Switch type: ON/OFF Switch and Pull Chain

Wattage: Max 60WBuilt in USB port

HAVE A QUESTION ABOUT YOUR PURCHASE?

OUR DEDICATED CUSTOMER SERVICES TEAM ARE HAPPY TO HELP CONTACT THEM VIA:

TELEPHONE: 020 3600 2255 EMAIL: cservice@oypla.com LIVE CHAT: www.oypla.com

PLEASE RETAIN A COPY OF THESE INSTRUCTIONS FOR FUTURE CONSULTATION



Environmental Protection

Products bearing the symbol shown below means that used electrical and electronic equipment (WEEE) should not be mixed with general household waste. For proper treatment, recovery and recycling, please take this product(s) to designated collection points where it will be accepted free of charge. Disposing of this product correctly will help save valuable resources and prevent any potential negative effects on human health and the environment, which could otherwise arise from inappropriate waste handling. Please contact your local authority for further details of your nearest designated collection point. Penalties may be applicable for incorrect disposal of this waste, in accordance with your national legislation.



Manual Version: V1.0 Model Code: 4748/4749