



User Manual

Model Code: 4849

THANK YOU FOR YOUR ORDER

Contents

- 1 Front Cover
 - -
- 2 Safety Instructions
 - _
- 2 Operating Instructions
 - ______
- 3 Back Cover

End



Coat Hooks

OYPLa

Contents

1 Front Cover

-

2 Safety Instructions

-

2 Operating Instructions

-

3

Back Cover

End

Safety Instructions

Notice: Ensure you read and fully understand instructions before use

While every attempt is made to ensure the highest degree of protection in all equipment, we cannot guarantee freedom from injury. The user assumes all risk of injury due to use. All merchandise is sold on this condition, which no representative of the company can waive or change.

- This product is not a toy, and is only to be used for its designated purpose.
- Never carry out alterations or modifications to this product.
- Please ensure you read the operating instructions carefully, to prevent any damage to doors.
- If the product is damaged or has any defects, please contact cservice@oypla.com

- This product is for indoor use only.
- Do not discard any of the packaging until you have checked that you have all the parts necessary.
- Make sure the product is tightly in place before use.
- Keep away from fire.
- Clean only using a damp cloth. Do not use strong industrial cleaning substances, as these may damage the product.

Warnings



The maximum weight capacity for the hooks is **10kg**. Do not exceed this.



Check for hidden pipes and cables before drilling into any walls.



Do not use a drill bit that is larger in girth than the wall plugs.

Operating Instructions

- 1. Whilst holding the hooks up to the desired mounting surface, gently use a pencil to mark the two screw holes. Use a spirit level to ensure the hooks are not slanted.
- 2. Remove the wall hooks from the mounting surface.
- 3. Using a drill, create the two holes for the wall plugs and screws. *Ensure you have checked for pipes and cables before drilling into any mounting surface. *Do not drill the holes deeper than they need to be. *Do not use a drill bit larger in girth than the wall plugs.
- 4. Insert the wall plugs into the newly created holes.
- 5. Hold the wall hooks back against the mounting surface, aligning with the two newly
- 6. Use a drill or screwdriver to insert the screws into the holes, with the hooks in between the screw and hole.
- 7. Cover the screw heads with the caps provided, if desired.

Model Code: 4849

Oypla.com LLP / www.oypla.com



Contents

1 Front Cover

-

2 Safety Instructions

-

2 Operating Instructions

-

3 Back Cover

End

HAVE A QUESTION ABOUT YOUR PURCHASE?

Our dedicated customer services team are happy to help. Contact them via:

Telephone: 020 3600 22 55
Email: cservice@oypla.com
Live Chat: WWW.OYPLA.COM

CONSIDER THE ENVIRONMENT!

In the United Kingdom, approximately 5 billion corrugated boxes are used per year amounting to around 83 per person! By recycling the cardboard box in which this product was packed, you contribute to the preservation and sustainability of the environment.

If you see a recycling logo on the packaging of your product, such as the below examples, that piece of packaging is recyclable. If there is not a recycling logo, please check with your local authorities before recycling.









PLEASE RETAIN A COPY OF THESE INSTRUCTIONS FOR FUTURE CONSULTATION



AN OFFICIAL OYPLA BRANDED PRODUCT

Model Code: 4849

Oypla.com LLP / www.oypla.com

