



Out of this world savings.

User Manual

Model: **4852**



Cigarette Bin

Safety Information

Please ensure you read and fully understand instructions before use

While every attempt is made to ensure the highest degree of protection in all equipment, we cannot guarantee freedom from injury. The user assumes all risk of injury due to use. All merchandise is sold on this condition, which no representative of the company can waive or change.

-
- This product should only be used for its designated purpose. Do not make alterations or modifications.
 - Ensure cigarette is fully extinguished before placing in the bin – if not, it can become a fire hazard.
 - Ensure the bin is emptied frequently, a full bin increases the risk of fire.
 - If the product is damaged or defective, please contact cservice@oypla.com
 - This product is intended for outdoor use only.
 - Clean only with a damp cloth. Do not use strong industrial cleaning substances as these may damage the product.
 - When disposing the contents of the bin, ensure to do so in an environmentally friendly manner.

Have a Question About Your Purchase?

Our dedicated customer services team are happy to help. Contact them via:

Telephone: 020 3600 22 55

Email: cservice@oypla.com

Live Chat: www.oypla.com

Consider the Environment!

By recycling the cardboard box in which this product was packed, you contribute towards helping the environment. If you see a recycling logo such as the below on the packaging, it can be recycled. If a recycling logo is not present, please check with your local authority before recycling.



PLEASE RETAIN A COPY OF THESE INSTRUCTIONS FOR FUTURE CONSULTATION

An Official Oypla Branded Product

Imported by Oypla.com LLP, Uxbridge, UB8 2FX

User Manual

Model Code: 4852

Oypla.com LLP / cservice@oypla.com